

Заправка картриджей Canon

Артикул	Принтер, МФУ	Копий	Цена руб.
703	Laser Shot LBP 2900 / 3000	2000	375
706	Canon LaserBase MF6530 / 6540PL / 6550 / 6560PL / 6580 / i-Sensys MF6530 / MF6540PL	5000	550
708	Laser Shot LBP 3300 / i-SENSYS LBP3360	2500	500
708H	Laser Shot LBP 3300 / i-SENSYS LBP3360	6000	700
710	Laser Shot LBP 3460	6000	750
710H	Laser Shot LBP 3460	12000	1000
712	LBP3010 / 3100	1500	375
713	i-SENSYS LBP 3250	2000	375
714	FAX-L3000 / L3000IP	4500	550
715	LBP-3310	3000	400
715H	LBP-3310	7000	700
052 (2199C002)	i-SENSYS LBP212 / LBP214 / LBP215 / MF421 / MF426 / MF428	3100	450
057 (3009c002)	LBP223dw / LBP226dw / LBP228x / MF443dw / MF445dw / MF446x / MF449x	3100	450
719	LBP 6300DN / LBP 6650DN / MF 5940DN / MF 5980DW	2100	450
719H	LBP 6300DN / LBP 6650DN / MF 5940DN / MF 5980DW	6400	600
724	LBP 6750 / 6750N / 6750DN	6000	750
724H	LBP 6750 / 6750N / 6750DN	12500	1000
725	i-SENSYS LBP-6000 / LBP-6000B	1600	375
726	i-SENSYS LBP-6200 / LBP-6200b	2100	375
728	i-SENSYS MF4410 / MF4430 / MF4450 / MF4550D / MF4570DN / MF4580DN	2100	375
737	i-SENSYS MF211 / 212 / 216 / 217 / 226 / 229	2400	375
Cartridge M	SmartBase PC1210D / PC1230D / PC1270D	5000	650
Cartridge T	FAX L400 / L380 / L380S / L390 / PC-D320 / D340	2500	400
EP-22	Laser Shot LBP-800 / 810 / 1120	2500	400
EP-25	Laser Shot LBP-3200	2500	400
EP-26 / EP-27	Laser Shot LBP 3200 / Laser Base MF3110 / MF5630 / 5650 / 5730 / 5750 / 5770	2500	400
EP-32	LBP-1000	5000	500
EP-52	LBP 1760 / 1760e	6000	650
EP-65	LBP-2000	10000	1000
FX-2	FAX L5000 / 5500 / 7000 / 7500	2700	400
FX-3	FAX-200 / 220 / 240 / 250 / 280 / 290 / 295 / 300 / 350 / 360 / MultiPASS L60 / L90	2700	400
FX-4	FAX L800 / L900	4000	500
FX-6	FAX- L3170 / L3175	5000	550
FX-7	FAX-L2000 / 2000IP	4500	550
FX-10	FAX L100 / L120 / i-SENSYS MF4120 / MF4140 / MF4150	2500	375
E16	FC-108 / 128 / 200 / 208 / 220 / 228 / 336 / PC-860 / 880 / 890	2000	500
E30	FC-108 / 128 / 200 / 208 / 220 / 228 / 336 / PC-860 / 880 / 890	4000	600

C-EXV14	iR-2016 / iR-2018 / iR-2020 / iR-2022 / iR-2025 / iR-2030 / iR-2318L	8300	600
C-EXV33 (2785B002)	iR-2520 / iR-2525 / iR-2530	14600	1500
C-EXV40	Canon iR1133 / iR1133A / iR1133iF	6000	550
C-EXV6	NP-7160 / NP-7161 / NP-7162 / NP-7163 / NP-7164 / NP-7210 / NP-7214	6900	700
NPG-11	NP6012 / 6112 / 6212 / 6312 / 6412 / 6512 / 6612	5000	500
A30	FC-1 / 2 / 3 / 3II / 5 / 5II / 22 / PC-6 / 7 / 7RE / 10 / 11	3000	400
701 B	LBP-5200	5000	2000
701 C,M,Y	LBP-5200	4000	2000
707 B	LBP 5000	2500	800
707 C,M,Y	LBP 5000	2000	800
710 B,C,M,Y	Laser Shot LBP 3460	2500	800
711 B,C,M,Y	LBP-5300 / LBP-5360 / MF-8450 / MF-9130 / MF-9170 / MF-9220 / MF-9280	6000	2500
716 B	i-SENSYS LBP-5050 / LBP-5970 / LBP-5975 / MF-8030 / MF-8050C	2300	600
716 C,M,Y	i-SENSYS LBP-5050 / LBP-5970 / LBP-5975 / MF-8030 / MF-8050C	1500	600
718 B	i-SENSYS LBP7200Cdn	3400	1400
718 C,M,Y	i-SENSYS LBP7200Cdn	2900	1400
723 B	LBP7750Cdn	5000	2000
723 C,M,Y	LBP7750Cdn	8500	2000
729 B	LBP7010C / LBP7018C	1200	500
729 C,M,Y	LBP7010C / LBP7018C	1000	500
731 B	LBP7100 / 7110	2400	500
731 C,M,Y	LBP7100 / 7110	1500	500