### SIPROTEC Compact 7SJ80 Multifunction Protection Relay



Fig. 5/56 SIPROTEC Compact 7SJ80 multifunction protection relay

#### Description

The SIPROTEC Compact 7SJ80 relays can be used for line/feeder protection of high and medium-voltage networks with grounded, low-resistance grounded, isolated or a compensated neutral point. The relays have all the required functions to be applied as a backup relay to a transformer differential relay.

The 7SJ80 features "flexible protection functions". 20 additional protection functions can be created by the user. For example, a rate of change of frequency function or a reverse power function can be created.

The relay provides circuit-breaker control, additional primary switching devices (grounding switches, transfer switches and isolating switches) can also be controlled from the relay. Automation or PLC logic functionality is also implemented in the relay. The integrated programmable logic (CFC) allows the user to add own functions, e.g. for the automation of switchgear (including: interlocking, transfer and load shedding schemes). The user is also allowed to generate user-defined messages.

The communication module is independent from the protection. It can easily be exchanged or upgraded to future communication protocols.

#### Highlights

Removable current and voltage terminals provide the ideal solution for fast and secure replacement of relays.

Binary input thresholds and current taps are software settings. There is thus no need to ever open the relay to adapt the hardware configuration to a specific application.

The relay provides 9 programmable function keys that can be used to replace pushbuttons, select switches and control switches.

The battery for event and fault recording memory can be exchanged from the front of the relay.

The relay is available with IEC 61850 for incredible cost savings in applications (e.g. transfer schemes with synch-check, bus interlocking and load shedding schemes).

This compact relay provides protection, control, metering and PLC logic functionality. Secure and easy to use one page matrix IO programming is now a standard feature.

The housing creates a sealed dust proof environment for the relay internal electronics. Heat build up is dissipated through the surface area of the steel enclosure. No dusty or corrosive air can be circulated over the electronic components. The relay thus will maintain its tested insulation characteristic standards per IEC, IEEE, even if deployed in harsh environment.

#### Function overview

#### Protection functions

- Time-overcurrent protection (50, 50N, 51, 51N)
- Directional time-overcurrent protection (67, 67N)
- Sensitive dir./non-dir. ground-fault detection (67Ns, 50Ns)
- Displacement voltage (59N/64)
- High-impedance restricted ground fault (87N)
- Inrush restraint
- Undercurrent monitoring (37)
- Overload protection (49)
- Under-/overvoltage protection (27/59)
- Under-/overfrequency protection (81O/U)
- Breaker failure protection (50BF)
- Phase unbalance or negative-sequence protection (46)
- Phase-sequence monitoring (47)
- Synch-check (25)
- Auto-reclosure (79)
- Fault locator (21FL)
- Lockout (86)

#### Control functions/programmable logic

- Commands for the ctrl. of CB, disconnect switches (isolators/isolating switches)
- Control through keyboard, binary inputs, DIGSI 4 or SCADA system
- User-defined PLC logic with CFC (e.g. interlocking)

#### Monitoring functions

- Operational measured values V, I, f
- Energy metering values  $W_{\rm p}, W_{\rm q}$
- Circuit-breaker wear monitoring
- Minimum and maximum values
- Trip circuit supervision (74TC)
- Fuse failure monitor
- 8 oscillographic fault records

#### Communication interfaces

- System/service interface
  - IEC 61850
  - IEC 60870-5-103
  - PROFIBUS-DP
  - DNP 3.0
- MODBUS RTU
- Ethernet interface for DIGSI 4
- USB front interface for DIGSI 4

#### Hardware

- 4 current transformers
- 0/3 voltage transformers
- 3/7 binary inputs (thresholds configurable using software)
- 5/8 binary outputs (2 changeover/ Form C contacts)
- 1 live-status contact
- Pluggable current and voltage terminals

Applicatio




Fig. 5/57 Function diagram

The SIPROTEC Compact 7SJ80 unit is a numerical protection relay that can perform control and monitoring functions and therefore provide the user with a costeffective platform for power system management, that ensures reliable supply of electrical power to the customers. The ergonomic design makes control easy from the relay front panel. A large, easy-to-read display was a key design factor.

#### Control

The integrated control function permits control of disconnect devices, grounding switches or circuit-breakers through the integrated operator panel, binary inputs, DIGSI 4 or the control or SCADA/automation system (e.g. SICAM, SIMATIC or other vendors automation system). A full range of command processing functions is provided.

#### Programmable logic

The integrated logic characteristics (CFC) allow the user to add own functions for automation of switchgear (e.g. interlocking) or switching sequence. The user can also generate user-defined messages. This functionality can form the base to create extremely flexible transfer schemes.

#### Line protection

The 7SJ80 units can be used for line protection of high and medium-voltage networks with grounded, low-resistance grounded, isolated or a compensated neutral point.

#### Transformer protection

The relay provides all the functions for backup protection for transformer differential protection. The inrush suppression effectively prevents unwanted trips that can be caused by inrush currents.

The high-impedance restricted groundfault protection detects short-circuits and insulation faults on the transformer.

#### **Backup protection**

The 7SJ80 can be used as a stand alone feeder protection relay or as a backup to other protection relays in more complex applications.

#### Metering values

Extensive measured values (e.g. I, V), metered values (e.g.  $W_p$ ,  $W_q$ ) and limit values (e.g. for voltage, frequency) provide improved system management.

#### Reporting

The storage of event logs, trip logs, fault records and statistics documents are stored in the relay to provide the user or operator all the key data required to operate modern substations.

## Switchgear cubicles for high/medium voltage

All units are designed specifically to meet the requirements of high/medium-voltage applications.

In general, no separate measuring instruments (e.g., for current, voltage, frequency, ...) or additional control components are necessary.

Typically the relay provides all required measurements, thus negating the use of additional metering devices like amp, volt or frequency meters. No additional control switches are required either. The relay provides 9 function keys that can be configured to replace pushbuttons and select switches.

1) Not available if function package 'Q' (synch-check, ANSI 25) is selected.

Application

ANSI No.	IEC	Protection functions
50, 50N	$I >, I >>, I >>>, I_E >, I_E >>, I_E >>>, I_E >>>$	Instantaneous and definite time-overcurrent protection (phase/neutral)
(51,51N)	$I_{\rm p}, I_{\rm Ep}$	Inverse time-overcurrent protection (phase/neutral)
67), 67N) <sup>1)</sup>	$I_{\text{dir}}$ >, $I_{\text{dir}}$ >>, $I_{p \text{ dir}}$ $I_{\text{Edir}}$ >, $I_{\text{Edir}}$ >>, $I_{\text{Ep dir}}$	Directional time-overcurrent protection (definite/inverse, phase/neutral), Directional comparison protection
$(67Ns)^{1)}, (50Ns)$	$I_{\rm EE}$ >, $I_{\rm EE}$ >>, $I_{\rm EEp}$	Directional/non-directional sensitive ground-fault detection
		Cold load pickup (dynamic setting change)
(59N/64) <sup>1)</sup>	V <sub>E</sub> , V <sub>0</sub> >	Displacement voltage, zero-sequence voltage
(87N)		High-impedance restricted ground-fault protection
(50BF)		Breaker failure protection
79		Auto-reclosure
25		Synch-check
46	<i>I</i> <sub>2</sub> >	Phase-balance current protection (negative-sequence protection)
(47)	V <sub>2</sub> >, phase-sequence	Unbalance-voltage protection and/or phase-sequence monitoring
49	$\vartheta >$	Thermal overload protection
37)	<i>I</i> <	Undercurrent monitoring
27,59	<i>V&lt;, V&gt;</i>	Undervoltage/overvoltage protection
(32) 1)	<i>P</i> <>, <i>Q</i> <>	Forward-power, reverse-power protection
(55) 1)	$\cos \varphi$	Power factor
(81O/U)	f>,f<	Overfrequency/underfrequency protection
(81R)	df/dt	Rate-of-frequency-change protection
(21FL) <sup>1)</sup>		Fault locator

1) Not available if function package  $^{\prime}\text{Q}^{\prime}$  (synch-check, ANSI 25) is selected.

#### Construction and hardware

## Connection techniques and housing with many advantages

The relay housing is 1/6 of a 19" rack. The housing is thus identical in size to the 7SJ50 and 7SJ60 relays that makes replacement very easy. The height is 244 mm (9.61").

Pluggable current and voltage terminals allow for pre-wiring and simplify the exchange of devices. CT shorting is done in the removable current terminal block. It is thus not possible to open-circuit a secondary current transformer.

All binary inputs are independent and the pick-up thresholds are settable using software settings (3 stages). The relay current transformer taps (1 A/5 A) are new software settings. Up to 9 function keys can be programmed for predefined menu entries, switching sequences, etc. The assigned function of the function keys can be shown in the display of the relay.

If a conventional (inductive) set of primary voltage transformers is not available in the feeder, the phase-to-ground voltages can be measured directly through a set of capacitor cones in the medium-voltage switchgear. In this case, the functions directional overcurrent protection (ANSI 67/67N), voltage protection (ANSI 27/59) and frequency protection (ANSI 81O/U) are available.

#### Protection functions

#### *Time-overcurrent protection* (ANSI 50, 50N, 51, 51N)

This function is based on the phaseselective measurement of the three phase currents and the ground current (four transformers). Three definite-time overcurrent protection elements (DMT) are available both for the phase and the ground elements. The current threshold and the delay time can be set in a wide range. Inverse-time overcurrent protection characteristics (IDMTL) can also be selected and activated.

#### Reset characteristics

Time coordination with electromechanical relays are made easy with the inclusion of the reset characteristics according to ANSI C37.112 and IEC 60255-3 /BS 142 standards. When using the reset characteristic (disk emulation), the reset process is initiated after the fault current has disappeared. This reset process corresponds to

	The seemens	Illuminated 6-line display
		munimated 0-mile display
		Navigation keys
	1 999	Numerical key pad/9 function keys
( 1.4 m m	oan	8 programmable LEDs
	0	Control keys
		Standard battery exchangeable from the front
	an and and an	USB front port



# 1.1.1.1.1.

Current terminal block



Voltage terminal block

Fig. 5/58 7SJ80 Front view, rear view, terminals

#### Available inverse-time characteristics

Characteristics acc. to	ANSI/IEEE	IEC 60255-3
Inverse	•	•
Short inverse	•	
Long inverse	•	•
Moderately inverse	•	
Very inverse	•	•
Extremely inverse	•	•

the reverse movement of the Ferraris disk of an electromechanical relay (disk emulation).

#### Inrush restraint

The relay features second harmonic restraint. If second harmonic content is detected during the energization of a transformer, the pickup of non-directional and directional elements are blocked.

#### Cold load pickup/dynamic setting change

The pickup thresholds and the trip times of the directional and non-directional time-overcurrent protection functions can be changed via binary inputs or by setable time control.

## Directional time-overcurrent protection (ANSI 67, 67N)

Directional phase and ground protection are separate functions. They operate in parallel to the non-directional overcurrent elements. Their pickup values and delay times can be set separately. Definite-time and inverse-time characteristics are offered. The tripping characteristic can be rotated by  $\pm$  180 degrees.

By making use of the voltage memory, the directionality can be determined reliably even for close-in (local) faults. If the primary switching device closes onto a fault and the voltage is too low to determine direction, the direction is determined using voltage from the memorized voltage. If no voltages are stored in the memory, tripping will be according to the set characteristic.

For ground protection, users can choose whether the direction is to be calculated using the zero-sequence or negativesequence system quantities (selectable). If the zero-sequence voltage tends to be very low due to the zero-sequence impedance it will be better to use the negativesequence quantities.


## Directional comparison protection (cross-coupling)

It is used for selective instantaneous tripping of sections fed from two sources, i.e. without the disadvantage of time delays of the set characteristic. The directional comparison protection is suitable if the distances between the protection zones are not significant and pilot wires are available for signal transmission. In addition to the directional comparison protection, the directional coordinated time-overcurrent protection is used for complete selective backup protection.

## (Sensitive) directional ground-fault detection (ANSI 59N/64, 67Ns, 67N)

For isolated-neutral and compensated networks, the direction of power flow in the zero sequence is calculated from the zerosequence current  $I_0$  and zero-sequence voltage  $V_0$ .

For networks with an isolated neutral, the reactive current component is evaluated; for compensated networks, the active current component or residual resistive current is evaluated. For special network conditions, e.g. high-resistance grounded networks with ohmic-capacitive



ground-fault current or low-resistance grounded networks with ohmic-inductive current, the tripping characteristics can be rotated approximately  $\pm$  45 degrees.

Two modes of ground-fault direction detection can be implemented: tripping or "signalling only mode".

It has the following functions:

- TRIP via the displacement voltage V<sub>E</sub>.
- Two instantaneous elements or one instantaneous plus one user-defined characteristic.
- Each element can be set to forward, reverse or non-directional.
- The function can also be operated in the insensitive mode as an additional short-circuit protection.

#### (Sensitive) ground-fault detection (ANSI 50Ns, 51Ns / 50N, 51N)

Forward

using cosine measurements

for compensated networks

For high-resistance grounded networks, a sensitive input transformer is connected to a phase-balance neutral current transformer (also called core-balance CT).

The function can also be operated in the normal mode as an additional shortcircuit protection for neutral or residual ground protection.

Reverse

## Phase-balance current protection (ANSI 46) (Negative-sequence protection)

By measuring current on the high side of the transformer, the two-element phasebalance current/negative-sequence protection detects high-resistance phase-to-phase faults and phase-to-ground faults on the low side of a transformer (e.g. Dy 5 or Delta/Star 150 deg.). This function provides backup protection for high-resistance faults through the transformer.

#### Breaker failure protection (ANSI 50BF)

If a faulted portion of the electrical circuit is not disconnected when a trip command is issued to a circuit-breaker, another trip command can be initiated using the breaker failure protection which trips the circuitbreaker of an upstream feeder. Breaker failure is detected if, after a trip command is issued and the current keeps on flowing into the faulted circuit. It is also possible to make use of the circuit-breaker position contacts (52a or 52b) for indication as opposed to the current flowing through the circuit-breaker.

## *High-impedance restricted ground-fault protection (ANSI 87N)*

The high-impedance measurement principle is a simple and sensitive method to detect ground faults, especially on transformers. It can also be used on motors, generators and reactors when they are operated on a grounded network.


When applying the high-impedance measurement principle, all current transformers in the protected area are connected in parallel and operated through one common resistor of relatively high R. The voltage is measured across this resistor (see Fig. 5/61). The voltage is measured by detecting the current through the (external) resistor *R* at the sensitive current measurement input  $I_{\text{EE}}$ . The varistor V serves to limit the voltage in the event of an internal fault. It limits the high instantaneous voltage spikes that can occur at current transformer saturation. At the same time, this results to smooth the voltage without any noteworthy reduction of the average value. If no faults have occurred and in the event of external or through faults, the system is at equilibrium, and the voltage through the resistor is approximately zero. In the event of internal faults, an imbalance occurs which leads to a voltage and a current flowing through the resistor R.


The same type of current transformers must be used and must at least offer a separate core for the high-impedance restricted ground-fault protection. They must have the same transformation ratio and approximately an identical knee-point voltage. They should also have only minimal measuring errors.

#### Auto-reclosure (ANSI 79)

Multiple re-close cycles can be set by the user and lockout will occur if a fault is present after the last re-close cycle. The following functions are available:

- 3-pole ARC for all types of faults
- Separate settings for phase and ground faults
- Multiple ARC, one rapid auto-reclosure (RAR) and up to nine delayed auto-reclosures (DAR)
- Initiation of the ARC is dependant on the trip command selected (e.g. 46, 50, 51, 67)
- The ARC function can be blocked by activating a binary input
- The ARC can be initiated from external or by the PLC logic (CFC)
- The directional and non-directional elements can either be blocked or operated non-delayed depending on the autoreclosure cycle
- If the ARC is not ready it is possible to perform a dynamic setting change of the directional and non-directional overcurrent elements





#### Flexible protection functions

The 7SJ80 enables the user to easily add up to 20 additional protective functions. Parameter definitions are used to link standard protection logic with any chosen characteristic quantity (measured or calculated quantity) (Fig. 5/62). The standard logic consists of the usual protection elements such as the pickup set point, the set delay time, the TRIP command, a block function, etc. The mode of operation for current, voltage, power and power factor quantities can be three-phase or singlephase. Almost all quantities can be operated with ascending or descending pickup stages (e.g. under and over voltage). All stages operate with protection priority.

Protection functions/stages available are based on the available measured analog quantities:

Function	ANSI No.
I>, I <sub>E</sub> >	50, 50N
V<, V>, V <sub>E</sub> >	27, 59, 64
$3I_0>, I_1>, I_2>, I_2/I_1$ $3V_0>, V_1><, V_2><$	50N, 46 59N, 47
P><, Q><	32
$\cos \varphi$ (p.f.)><	55
<i>f&gt;&lt;</i>	81O, 81U
df/dt><	81R

For example, the following can be implemented:

- Reverse power protection (ANSI 32R)
- Rate-of-frequency-change protection (ANSI 81R)




Fig. 5/62 Flexible protection functions

#### Synch-check (ANSI 25)

When closing a circuit-breaker, the units can check whether two separate networks are synchronized. Voltage-, frequency- and phase-angle-differences are checked to determine whether synchronous conditions exist.

#### Trip circuit supervision (ANSI 74TC)

One or two binary inputs can be used for monitoring the circuit-breaker trip coil including its incoming cables. An alarm signal is generated whenever the circuit is interrupted. The circuit breaker trip coil is monitored in the open and closed position. Interlocking features can be implemented to ensure that the beaker can only be closed if the trip coil is functional.

#### Lockout (ANSI 86)

All binary output statuses can be memorized. The LED reset key is used to reset the lockout state. The lockout state is also stored in the event of supply voltage failure. Reclosure can only occur after the lockout state is reset.

#### Thermal overload protection (ANSI 49)

To protect cables and transformers, an overload protection function with an integrated warning/alarm element for temperature and current can be used. The temperature is calculated using a thermal homogeneous body model (per IEC 60255-8), it considers the energy entering the equipment and the energy losses. The calculated temperature is constantly adjusted according to the calculated losses. The function considers loading history and fluctuations in load.

#### Settable dropout delay times

If the relays are used in conjunction with electromechanical relays, in networks with intermittent faults, the long dropout times of the electromechanical relay (several hundred milliseconds) can lead to problems in terms of time coordination/grading. Proper time coordination/grading is only possible if the dropout or reset time is approximately the same. This is why the parameter for dropout or reset times can be defined for certain functions such as time-overcurrent protection, ground short-circuit and phase-balance current protection.

#### Undercurrent monitoring (ANSI 37)

A sudden drop in current, which can occur due to a reduced load, is detected with this function. This may be due to shaft that breaks, no-load operation of pumps or fan failure.

#### Voltage protection

#### Overvoltage protection (ANSI 59)

The two-element overvoltage protection detects unwanted network and machine overvoltage conditions. The function can operate either with phase-to-phase, phase-to-ground, positive phase-sequence or negative phase-sequence voltage. Three-phase and single-phase connections are possible.

#### Undervoltage protection (ANSI 27)

The two-element undervoltage protection provides protection against dangerous voltage drops (especially for electric machines). Applications include the isolation of generators or motors from the network to avoid undesired operating conditions and a possible loss of stability. Proper operating conditions of electrical machines are best evaluated with the positivesequence quantities. The protection function is active over a wide frequency range (45 to 55, 55 to 65 Hz). Even when falling below this frequency range the function continues to work, however, with decrease accuracy.

The function can operate either with phase-to-phase, phase-to-ground or positive phase-sequence voltage, and can be monitored with a current criterion. Threephase and single-phase connections are possible.

#### Frequency protection (ANSI 810/U)

Frequency protection can be used for overfrequency and underfrequency protection. Electric machines and parts of the system are protected from unwanted frequency deviations. Unwanted frequency changes in the network can be detected and the load can be removed at a specified frequency setting.

Frequency protection can be used over a wide frequency range (40 to 60 (for 50 Hz), 50 to 70 (for 60 Hz). There are four elements (individually set as overfrequency, underfrequency or OFF) and each element can be delayed separately. Blocking of the frequency protection can be performed by activating a binary input or by using an undervoltage element.

#### Fault locator (ANSI 21FL)

The integrated fault locator calculates the fault impedance and the distance to fault. The results are displayed in  $\Omega$ , kilometers (miles) and in percent of the line length.

#### Customized functions (ANSI 51V, etc.)

Additional functions, which are not time critical, can be implemented using the CFC measured values. Typical functions include reverse power, voltage controlled overcurrent, phase angle detection, and zerosequence voltage detection.

#### Control and automatic functions

#### Control

In addition to the protection functions, the SIPROTEC 4 and SIPROTEC Compact units also support all control and monitoring functions that are required for operating medium-voltage or high-voltage substations.

The main application is reliable control of switching and other processes.

The status of primary equipment or auxiliary devices can be obtained from auxiliary contacts and communicated to the 7SJ80 via binary inputs. Therefore it is possible to detect and indicate both the OPEN and CLOSED position or a fault or intermediate circuit-breaker or auxiliary contact position.

The switchgear or circuit-breaker can be controlled via:

- integrated operator panel
- binary inputs
- substation control and protection system
   DIGSI 4

#### Automation / user-defined logic

With integrated logic, the user can create, through a graphic interface (CFC), specific functions for the automation of switchgear or a substation. Functions are activated using function keys, a binary input or through the communication interface.

#### Switching authority

Switching authority is determined by set parameters or through communications to the relay. If a source is set to "LOCAL", only local switching operations are possible. The following sequence for switching authority is available: "LOCAL"; DIGSI PC program, "REMOTE".

There is thus no need to have a separate Local/Remote switch wired to the breaker coils and relay. The local/remote selection can be done using a function key on the front of the relay.

#### Command processing

This relay is designed to be easily integrated into a SCADA or control system. Security features are standard and all the functionality of command processing is offered. This includes the processing of single and double commands with or without feedback, sophisticated monitoring of the control hardware and software, checking of the external process, control actions using functions such as runtime monitoring and automatic command termination after output. Here are some typical applications:

- Single and double commands using 1, 1 plus 1 common or 2 trip contacts
- · User-definable bay interlocks
- Operating sequences combining several switching operations such as control of circuit-breakers, disconnectors and grounding switches
- Triggering of switching operations, indications or alarm by combination with existing information

#### Assignment of feedback to command

The positions of the circuit-breaker or switching devices and transformer taps are acquired through feedback. These indication inputs are logically assigned to the corresponding command outputs. The unit can therefore distinguish whether the indication change is a result of switching operation or whether it is an undesired spontaneous change of state.




Fig. 5/63 CB switching cycle diagram

#### Chatter disable

The chatter disable feature evaluates whether, in a set period of time, the number of status changes of indication input exceeds a specified number. If exceeded, the indication input is blocked for a certain period, so that the event list will not record excessive operations.

#### Indication filtering and delay

Binary indications can be filtered or delayed.

Filtering serves to suppress brief changes in potential at the indication input. The indication is passed on only if the indication voltage is still present after a set period of time. In the event of an indication delay, there is a delay for a preset time. The information is passed on only if the indication voltage is still present after this time.

#### Indication derivation

User-definable indications can be derived from individual or a group of indications. These grouped indications are of great value to the user that need to minimize the number of indications sent to the system or SCADA interface.

#### **Further functions**

#### Measured values

The r.m.s. values are calculated from the acquired current and voltage along with the power factor, frequency, active and reactive power. The following functions are available for measured value processing:

- Currents  $I_{L1}$ ,  $I_{L2}$ ,  $I_{L3}$ ,  $I_E$ ,  $I_{EE}$  (67Ns)
- Voltages *V*<sub>L1</sub>, *V*<sub>L2</sub>, *V*<sub>L3</sub>, *V*<sub>L1L2</sub>, *V*<sub>L2L3</sub>, *V*<sub>L3L1</sub>
- Symmetrical components *I*<sub>1</sub>, *I*<sub>2</sub>, 3*I*<sub>0</sub>; *V*<sub>1</sub>, *V*<sub>2</sub>, *V*<sub>0</sub>
- Power Watts, Vars, VA/P, Q, S (P, Q: total and phase selective)
- Power factor (cos φ), (total and phase selective)
- Frequency
- Energy ± kWh, ± kVarh, forward and reverse power flow
- Mean as well as minimum and maximum current and voltage values
- Operating hours counter
- Mean operating temperature of the overload function
- Limit value monitoring Limit values can be monitored using programmable logic in the CFC. Commands can be derived from this limit value indication.
- Zero suppression In a certain range of very low measured values, the value is set to zero to suppress interference.

#### Metered values

For internal metering, the unit can calculate an energy metered value from the measured current and voltage values. If an external meter with a metering pulse output is available, the 7SJ80 can obtain and process metering pulses through an indication input.

The metered values can be displayed and passed on to a control center as an accumulated value with reset. A distinction is made between forward, reverse, active and reactive energy.

#### Circuit-breaker wear monitoring

Methods for determining circuit-breaker contact wear or the remaining service life of a circuit-breaker (CB) allow CB maintenance intervals to be aligned to their actual degree of wear. The benefit lies in reduced maintenance costs. There is no exact mathematical method to calculate the wear or the remaining service life of a circuit-breaker that takes arcchamber's physical conditions into account when the CB opens. This is why various methods of determining CB wear have evolved which reflect the different operator philosophies. To do justice to these, the relay offers several methods:

•  $\Sigma I^x$ , with x = 1...3

•  $\sum i^2 t$ 

The devices also offer a new method for determining the remaining service life:

• Two-point method

The CB manufacturers double-logarithmic switching cycle diagram (see Fig. 5/63) and the breaking current at the time of contact opening serve as the basis for this method. After CB opening, the two-point method calculates the remaining number of possible switching cycles. Two points P1 and P2 only have to be set on the device. These are specified in the CB's technical data.

All of these methods are phase-selective and a limit value can be set in order to obtain an alarm if the actual value falls below or exceeds the limit value during determination of the remaining service life.

#### Commissioning

Commissioning could not be easier and is supported by DIGSI 4. The status of the binary inputs can be read individually and the state of the binary outputs can be set individually. The operation of switching elements (circuit-breakers, disconnect devices) can be checked using the switching functions of the relay. The analog measured values are represented as wideranging operational measured values. To prevent transmission of information to the control center during maintenance, the communications can be disabled to prevent unnecessary data from being transmitted. During commissioning, all indications with test tag for test purposes can be connected to a control and protection system.

#### Test operation

During commissioning, all indications can be passed to a control system for test purposes.

<sup>•</sup>  $\Sigma I$ 

#### Communication

The relay offers flexibility with reference to its communication to substation automation systems and industrial SCADA or DCS systems. The communication module firmware can be changed to communicate using another protocol or the modules can be changed completely for a different connection or protocol. It will thus be possible to move to future communication protocols like popular Ethernet-based protocols with ease.

#### USB interface

There is an USB interface on the front of the relay. All the relay functions can be set using a PC and DIGSI 4 protection operation program. Commissioning tools and fault analysis are built into the DIGSI program and are used through this interface.

#### Interfaces

A number of communication modules suitable for various applications can be fitted at the bottom of the housing. The modules can be easily replaced by the user. The interface modules support the following applications:

- System/service interface Communication with a central control system takes place through this interface. Radial or ring type station bus topologies can be configured depending on the chosen interface. Furthermore, the units can exchange data through this interface via Ethernet and the IEC 61850 protocol and can also be accessed using DIGSI.
- Ethernet interface The Ethernet interface was implemented for access to a number of protection units using DIGSI.

#### System interface protocols (retrofittable)

#### IEC 61850 protocol

Since 2004, the Ethernet-based IEC 61850 protocol is a global standard for protection and control systems used by power utilities. Siemens was the first manufacturer to implement this standard. This protocol makes peer-to-peer communication possible. It is thus possible to set up masterless systems to perform interlocking or transfer schemes. Configuration is done using DIGSI.

#### IEC 60870-5-103 protocol


The IEC 60870-5-103 protocol is an international standard for the transmission of protective data and fault recordings. All messages from the unit and also control commands can be transferred by means of published, Siemens-specific extensions to the protocol. As a further option a redundant IEC 60870-5-103 module is available as well. With the redundant module it will be possible to read and change single parameters.


#### **PROFIBUS-DP protocol**

PROFIBUS-DP is a widespread protocol in industrial automation. Through PROFIBUS-DP, SIPROTEC units make their information available to a SIMATIC controller or receive commands from a central SIMATIC controller or PLC. Measured values can also be transferred to a PLC master.

#### MODBUS RTU protocol

This simple, serial protocol is mainly used in industry and by power utilities, and is supported by a number of relay manufacturers. SIPROTEC units function as MODBUS slaves, making their information available to a master or receiving information from it. A time-stamped event list is available.








Fig. 5/65 Bus structure for station bus with Ethernet and IEC 61850, fiber-optic ring

#### Communication

#### DNP 3.0 protocol

Power utilities use the serial DNP 3.0 (Distributed Network Protocol) for the station and network control levels. SIPROTEC units function as DNP slaves, supplying their information to a master system or receiving information from it.

## System solutions for protection and station control

Units featuring IEC 60870-5-103 interfaces can be connected to SICAM in parallel via the RS485 bus or radially by fiber-optic link. Through this interface, the system is open for the connection to other manufacturers systems (see Fig. 5/64).

Because of the standardized interfaces, SIPROTEC units can also be integrated into systems of other manufacturers or in SIMATIC. Electrical RS485 or optical interfaces are available. The best physical data transfer medium can be chosen thanks to opto-electrical converters. Thus, the RS485 bus allows low-cost wiring in the cubicles and an interference-free optical connection to the master can be established.

For IEC 61850, an interoperable system solution is offered with SICAM. Through the 100 Mbits/s Ethernet bus, the units are linked with SICAM electrically or optically to the station PC. The interface is standardized, thus also enabling direct connection to relays of other manufacturers and into the Ethernet bus. With IEC 61850, however, the relays can also be used in other manufacturers' systems (see Fig. 5/65).




Fig. 5/66 System solution/communication




Fig. 5/67 Optical Ethernet communication module for IEC 61850 with integrated Ethernet-switch


#### Typical connections

Connection of current and voltage transformers

#### Standard connection

For grounded networks, the ground current is obtained from the phase currents by the residual current circuit.










Fig. 5/70 Residual current circuit with directional element

#### Typical connections

#### Connection for compensated networks

The figure shows the connection of two phase-to-ground voltages and the  $V_{\rm E}$  voltage of the broken delta winding and a phase-balance neutral current transformer for the ground current. This connection maintains maximum precision for directional ground-fault detection and must be used in compensated networks.






Fig. 5/72 shows sensitive directional ground-fault detection.





Fig. 5/72 Sensitive directional ground-fault detection

#### Connection for the synch-check function

Open delta voltages and residual  $I_{\rm N}$  connection. Single-phase connection for synch-check.



**Fig. 5/73** Measuring of the busbar voltage and the outgoing feeder voltage for synchronization

#### Typical applications

#### Overview of connection types

Type of network	Function	Current connection	Voltage connection
(Low-resistance) grounded network	Time-overcurrent protection phase/ground non-directional	Residual circuit, with 3 phase-current transformers required, phase-balance neutral current transformer possible	_
(Low-resistance) grounded networks	Sensitive ground-fault protection	Phase-balance neutral current transformers required	-
Isolated or compensated networks	Time-overcurrent protection phases non-directional	Residual circuit, with 3 or 2 phase current transformers possible	-
(Low-resistance) grounded networks	Time-overcurrent protection phases directional	Residual circuit, with 3 phase-current transformers possible	Phase-to-ground connection or phase-to-phase connection
Isolated or compensated networks	Time-overcurrent protection phases directional	Residual circuit, with 3 or 2 phase- current transformers possible	Phase-to-ground connection or phase-to-phase connection
(Low-resistance) grounded networks	Time-overcurrent protection ground directional	Residual circuit, with 3 phase-current transformers required, phase-balance neutral current transformers possible	Phase-to-ground connection required
Isolated networks	Sensitive ground-fault protection	Residual circuit, if ground current $> 0.05 I_N$ on secondary side, otherwise phase-balance neutral current transformers required	3 times phase-to-ground connection or phase-to-ground connection with broken delta winding
Compensated networks	Sensitive ground-fault protection $\cos \varphi$ measurement	Phase-balance neutral current transformers required	3 times phase-to-ground connection or phase-to-ground connection with broken delta winding

## 

#### Technical data

#### General unit data

 Analog current inputs

 Rated frequency  $f_N$  

 Rated current  $I_{nom}$  

 Ground current, sensitive  $I_{Ns}$  

 Burden per phase and ground path at  $I_{nom} = 1$  A at  $I_{nom} = 5$  A for sensitive ground fault detection at 1 A

 Load capacity current path Thermal (rms)

Dynamic (peak value) Loadability input for sensitive ground-fault detection  $I_{\rm Ns}{}^{1)}$ Thermal (rms)

Dynamic (peak value)

Analog voltage inputs

Rated voltage

Measuring range
Burden at 100 V
Overload capacity in voltage path Thermal (rms)
Input voltage range UL

#### Auxiliary voltage

DC voltage

Voltage supply via an integrated converter

Rated auxiliary voltage V <sub>aux</sub>	DC	24 to 48 V	60 to 250 V
Permissible voltage ranges	DC	19 to 60 V	48 to 300 V
AC ripple voltage, peak-to-peak IEC 60255-11	ζ,	$\leq$ 15 % of the auxilia	ry voltage
Power input Quiescent Energized		Approx. 5 W Approx. 12 W	
Bridging time for failure/ short-circuit, IEC 60255-11 (in the quiescent state)		$\geq$ 50 ms at $V \geq$ 110 V $\geq$ 10 ms at $V <$ 110 V	
<u>AC voltage</u>			
Voltage supply via an integrated converter	ł		
Rated auxiliary voltage V <sub>aux</sub>	AC	115 V	230 V
Permissible voltage ranges	AC	92 to 132 V	184 to 265 V
Power input (at 115 V AC/230 V Quiescent Energized		Approx. 5 VA Approx. 12 VA	
Bridging time for failure/short- circuit (in the quiescent state)		$\geq 10 \text{ ms at } V = 115/2$	30 V AC

50 or 60 Hz (adjustable) 1 or 5 A  $\leq 1.6 \cdot I_{\text{nom}}$  linear range<sup>1)</sup> **Binary** inputs

Approx. 0.05 VA Approx. 0.3 VA Approx. 0.05 VA

500 A for 1 s 150 A for 10 s 20 A continuous 1250 A (half-cycle)

300 A for 1 s 100 A for 10 s 15 A continuous 750 A (half-cycle)

300 V

34 to 225 V (phase-to-ground connection) 34 to 200 V (phase-to-phase connection) 0 to 200 V Approx. 0.005 VA 230 V continuous

7SJ802/804 7SJ801/803 Type Number (marshallable) 3 7 Rated voltage range 24 to 250 V DC Current input, energized Approx. 0.4 mA (independent of the control voltage) Secured switching thresholds (adjustable) for rated voltages V high > 19 V DC24 to 125 V DC  $V \log < 10 V DC$ for rated voltages V high > 88 V DC110 to 250 V DC  $V \log < 44 \text{ V DC}$ for rated voltages V high > 176 V DC220 and 250 V DC  $V \log < 88 V DC$ Maximum permissible voltage 300 V DC 220 V DC across 220 nF at a Input interference suppression recovery time between two switching operations  $\geq 60 \text{ ms}$ Output relay 7SJ801/803 7SJ802/804 Type NO contact 3 6 NO/NC selectable 2(+1) live contact 2(+1) live contact not allocatable) not allocatable) Max. 1000 W/VA Switching capability MAKE Switching capability BREAK 40 W or 30 VA at  $L/R \le 40$  ms 250 V DC/AC Switching voltage Admissible current per contact 5 A (continuous) Permissible current per contact 30 A for 1 s (NO contact) (close and hold) Electrical tests Specification Standards IEC 60255 (product standard) ANSI/ IEEE C37.90 see individual functions VDE 0435 for more standards see also individual functions Insulation tests Standards IEC 60255-27 and IEC 60870-2-1 High-voltage test (routine test) 2.5 kV, 50 Hz All circuits except power supply, binary inputs, communication interface High-voltage test (routine test) 3.5 kV DC Auxiliary voltage and binary inputs High-voltage test (routine test) 500 V, 50 Hz Only isolated communication interfaces (A and B)

Impulse voltage test (type test) All process circuits (except communication interfaces) against the internal electronics

1) Only in models with input for sensitive ground-fault detection (see ordering data)

6 kV (peak value); 1.2/50 μs; 0.5 J;

intervals of 1 s

3 positive and 3 negative impulses at

#### Insulation tests (cont'd)

Impulse voltage test (type test) All process circuits (except communication interfaces) against each other and against the productive conductor terminal class III

#### EMC tests for immunity; type tests

Standards

1 MHz check, class III IEC 60255-22-1; IEC 61000-4-18; IEEE C37.90.1 Electrostatic discharge, class IV IEC 60255-22-2 and IEC 61000-4-2

Radio frequency electromagnetic field, amplitude-modulated, class III IEC 60255-22-3; or IEC 61000-4-3

Fast transient disturbance variables/ burst, class IV IEC 60255-22-4 and IEC 61000-4-4, IEEE C37.90.1

High-energy surge voltages (SURGE), Impulse: 1.2/50 µs Installation class III IEC 60255-22-5; IEC 61000-4-5 Auxiliary voltage

Measuring inputs, binary inputs and relay outputs

HF on lines, amplitude-modulated, class III; IEC 60255-22-6; IEC 61000-4-6,

Power system frequency magnetic field

IEC 61000-4-8, class IV

ANSI/IEEE C37.90.2

Damped oscillations IEC 61000-4-18

IEC 60255-6 and -22

intervals of 1 s

5 kV (peak value); 1.2/50 µs; 0.5 J;

3 positive and 3 negative impulses at

(product standard) IEC/EN 61000-6-2 VDE 0435 For more standards see individual functions 2.5 kV (peak); 1 MHz;  $\tau = 15 \,\mu s$ ; 400 surges per s; test duration 2 s;  $R_i = 200 \Omega$ 8 kV contact discharge; 15 kV air discharge; both polarities; 150 pF;  $R_i = 330 \Omega$ 10 V/m; 80 MHz to 2.7 GHz; 80 % AM; 1 kHz

4 kV; 5/50 ns; 5 kHz; burst length = 15 ms; repetition rate 300 ms; both polarities;  $R_i = 50 \Omega$ ; test duration 1 min

Common mode: 4 kV; 12 Ω; 9 μF Diff. mode: 1 kV; 2 Ω; 18 μF Common mode: 4 kV; 42  $\Omega$ ; 0.5  $\mu$ F Diff. mode: 1 kV; 42 Ω; 0.5 μF 10 V; 150 kHz to 80 MHz; 80 % AM; 1 kHz

30 A/m continuous; 300 A/m for 3 s

Radiated electromagnetic interference 20 V/m; 80 MHz to 1 GHz; 80 % AM; 1 kHz 2.5 (peak value) 100 kHz; 40 pulses per s; test duration 2 s;  $R_i = 200 \Omega$ 

#### EMC tests for noise emission; type tests Standard

IEC/EN 61000-6-4 Radio noise voltage to lines, only 150 kHz to 30 MHz, limit class A auxiliary voltage IEC/CISPR 11

30 to 1000 MHz, limit class A

#### Mechanical stress tests

Interference field strength

IEC/CISPR 11

#### Vibration, shock stress and seismic vibration

During stationary operation Standards Oscillation IEC 60255-21-1, class II; IEC 60068-2-6

IEC 60255-21 and IEC 60068 Sinusoidal 10 to 60 Hz:  $\pm$  0.075 mm amplitude; 60 to 150 Hz: 1 g acceleration Frequency sweep rate 1 octave/min 20 cycles in 3 orthogonal axes

Shock IEC 60255-21-2, class I; IEC 60068-2-27 Seismic vibration

IEC 60255-21-3, class II; IEC 60068-3-3

#### During transport

Standards Vibration IEC 60255-21-1, class II; IEC 60068-2-6

Shock IEC 60255-21-2, class I; IEC 60068-2-27

Continuous shock IEC 60255-21-2, class I; IEC 60068-2-29

#### **Climatic stress tests**

Temperatures		
Standards	IEC 60255-6	
Type test (in acc. with IEC 60068-2-1 and -2, Test Bd for 16 h)	–25 °C to +85 °C or –13 °F to +185 °F	
Permissible temporary operating temperature (tested for 96 h)	-20 °C to +70 °C or -4 °F to +158 °F (clearness of the display may be impaired from +55 °C or +131 °F)	
Recommended for permanent operation (in acc. with IEC 60255-6)	–5 °C to +55 °C or +23 °F to +131 °F	
Limit temperatures for storage	–25 °C to +55 °C or –13 °F to +131 °F	
Limit temperatures for transport	–25 °C to +70 °C or –13 °F to +158 °F	
Storage and transport with factory packaging		
Humidity		
Permissible humidity	Mean value per year $\leq$ 75 % relative humidity; on 56 days of the year up to 93 % relative humidity; condensa- tion must be avoided!	

Semi-sinusoidal

(horizontal axis)

(horizontal axis)

(vertical axis)

(vertical axis)

Sinusoidal

Semi-sinusoidal

of the 3 axes)

of the 3 axes)

Semi-sinusoidal

Sinusoidal

5 g acceleration, duration 11 ms; each

3 shocks (in both directions of 3 axes)

1 to 8 Hz:  $\pm$  7.5 mm amplitude

1 to 8 Hz: ± 3.5 mm amplitude

8 to 35 Hz: 2 g acceleration

8 to 35 Hz: 1 g acceleration

Frequency sweep 1 octave/min

1 cycle in 3 orthogonal axes

IEC 60255-21 and IEC 60068

5 to 8 Hz:  $\pm$  7.5 mm amplitude

Frequency sweep 1 octave/min

15 g acceleration, duration 11 ms,

each 3 shocks (in both directions

10 g acceleration, duration 16 ms,

each 1000 shocks (in both directions

20 cycles in 3 orthogonal axes

8 to 150 Hz; 2 g acceleration

It is recommended that all devices be installed such that they are not exposed to direct sunlight, nor subject to large fluctuations in temperature that may cause condensation to occur.

#### Unit design Туре 7SJ80\*\*-\*B 7SJ80\*\*-\*/E 7XP20 Housing Dimensions See dimension drawings Housing width 1/61/6Weight in kg 4.5 kg (9.9 lb) Surface-mounting 4 kg (8.8 lb) Flush-mounting

#### Unit design (cont'd)

Communication interfaces

Degree of protection acc. to EN 60529	
For equipment in the surface-mounting housing	IP 50
For equipment in the flush-mounting housing	Front IP 51 Back IP 50
For operator protection	IP 2x for current t IP 1x for voltage t
Degree of pollution, IEC 60255-27	2

<b>Operating interface</b> (front of unit)		
Terminal	USB, type B	
Transmission speed	Up to 12 Mbit/s	
Bridgeable distance	5 m	
Ethernet service interface (Port A)		
Ethernet electrical for DIGSI		

Operation	Wi
Terminal	At 1
	mo
	100
	LEI
	LEI
	(0)
Test voltage	500
Transmission speed	10/

#### Trans Bridgeable distance Service interface for DIGSI 4/modem (Port B) Isolated RS 232/RS 485

Terminal

Test voltage Transmission rate Bridgeable distance RS232 Bridgeable distance RS485 Fiber optic (FO) Terminal

Optical wavelength Permissible path attenuation Bridgeable distance

#### System interface (Port B) IEC 60870-5-103 protocol, single

RS 232/RS 485 Terminal

#### Test voltage Transmission rate

Bridgeable distance RS232 Bridgeable distance RS485

terminal terminal

With DIGSI the bottom part of the housing, ounting location "A", RJ45 socket, 0BaseT in acc. with IEEE 802.3 D yellow: 10/100 Mbit/s (ON/OFF) D green: connection/no connection N/OFF) 0 V/50 Hz /100 Mbit/s 20 m (66 ft) At the bottom part of the housing,

9-pin subminiature connector (SUB-D) 500 V/50 Hz Min. 1200 Bd, max. 115200 Bd Max. 15 m/49.2 ft Max. 1 km/3300 ft

At the bottom part of the housing, ST connector  $\lambda=820\ nm$ Max. 8 dB, for glass fiber 62.5/125 µm Max. 1.5 km/0.9 miles

At the bottom part of the housing, mounting location "B", 9-pin subminiature connector (SUB-D) 500 V/50 Hz Min. 1200 Bd, max. 115000 Bd, factory setting 9600 Bd 15 m/49.2 ft 1 km/3300 ft

System interface			
IEC 60870-5-103 protocol, single (co	ntinued)		
<u>Fiber optic</u>			
Connection fiber-optic cable	ST connector		
Terminal	At the bottom part of the housing, mounting location "B"		
Optical wavelength	$\lambda = 820 \text{ nm}$		
Permissible path attenuation	Max. 8 dB, for glass fiber 62.5/125 $\mu m$		
Bridgeable distance	Max. 1.5 km/0.9 miles		
IEC 60870-5-103 protocol, redundar	nt		
RS485, isolated			
Terminal	At the bottom part of the housing, mounting location "B", RJ45 socket		
Test voltage	500 V/50 Hz		
Transmission rate	Min. 2400 Bd, max. 57600 Bd; factory setting 19200 Bd		
Bridgeable distance RS485	Max. 1 km/3300 ft		
IEC 61850 protocol			
Ethernet, electrical (EN100) for IEC 6	1850 and DIGSI		
Terminal	At the bottom part of the housing, mounting location "B", two RJ45 connectors, 100BaseT in acc. with IEEE 802.3		
Test voltage	500 V/50 Hz		
Transmission rate	100 Mbit/s		
Bridgeable distance	Max. 20 m/65.6 ft		
Ethernet, optical (EN100) for IEC 618	350 and DIGSI		
Terminal	At the bottom part of the housing, mounting location "B", LC connector, 100BaseT in acc. with IEEE 802.3		
Transmission rate	100 Mbit/s		
Optical wavelength	$\lambda = 1300 \text{ nm}$		
Bridgeable distance	max. 2 km/1.24 miles		
PROFIBUS DP			
RS485, isolated			
Terminal	At the bottom part of the housing, mounting location "B", 9-pin subminiature connector (SUB-D)		
Test voltage	500 V/50 Hz		
Transmission rate	Up to 1.5 Mbaud		
Bridgeable distance	1000 m/3300 ft ≤ 93.75 kbaud; 500 m/1640 ft ≤ 187.5 kbaud; 200 m/656 ft ≤ 1.5 Mbaud		
<u>Fiber optic</u>			
Connection fiber-optic cable	ST connector, double ring		
Terminal	At the bottom part of the housing, mounting location "B"		
Optical wavelength	$\lambda = 820 \text{ nm}$		
Permissible path attenuation	Max. 8 dB, for glass fiber 62.5/125 $\mu m$		
Bridgeable distance	Max. 2 km/1.24 miles		
MODBUS RTU, DNP 3.0			
<u>RS485</u>			
Terminal	At the bottom part of the housing, mounting location "B", 9-pin subminiature connector (SUB-D)		

Revised July 2010

Test voltage

500 V/50 Hz

#### System interface (cont'd) Transmission rate Bridgeable distance Fiber optic Connection fiber-optic cable Terminal Optical wavelength Permissible path attenuation

Up to 19200 baud Max. 1 km/3300 ft

ST connector transmitter/receiver At the bottom part of the housing, mounting location "B"  $\lambda = 820 \text{ nm}$ Max. 8 dB, for glass fiber 62.5/125 µm Max. 1.5 km/0.9 miles

#### Functions

Bridgeable distance

Definite-time overcurrent protection, directional/non-directional (ANSI 50, 50N, 67, 67N) 3-phase (standard) or 2-phase Operating modes A (L1) and C (L3) Number of elements (stages) 50-1, 50-2, 50-3 (I>, I>>, I>>>) (phases) 50N-1, 50N-2, 50N-3 ( $I_E$ >,  $I_E$ >>,  $I_{\rm E} >>>)$  (ground) Setup setting ranges 0.5 to 175 A or  $\infty^{1}$  (in steps of 0.01 A) Pickup current 50-1, 50-2, 50-3 (phases) 0.25 to 175 A or  $\infty^{11}$  (in steps of 0.01 A) Pickup current 50N-1, 50N-2, 50N-3 (ground) 0 to 60 s or  $\infty$  (in steps of 0.01 s) Delay times T Dropout delay time 50/50N 0 to 60 s (in steps of 0.01 s) TDROPOUT (DO) Times Pickup times (without inrush restraint, with inrush restraint +10 msWith twice the setting value Approx. 30 ms With ten times the setting value Approx. 20 ms Dropout time Approx. 30 ms Approx. 0.95 for  $I/I_{nom} \ge 0.3$ Dropout ratio Tolerances 3 % of setting value or 75 mA<sup>1)</sup> Pickup Delay times  $T, T_{DO}$ 1 % or 10 ms Inverse-time overcurrent protection, directional/non-directional (ANSI 51, 51N, 67, 67N) 3-phase (standard) or Operating mode 2-phase A (L1) and C (L3) Setting ranges  $\begin{array}{l} 0.5 \text{ to } 20 \text{ A}^{1)} \text{ (in steps of } 0.01 \text{ A}) \\ 0.25 \text{ to } 20 \text{ A}^{1)} \text{ (in steps of } 0.01 \text{ A}) \end{array}$ Pickup currents 51 (phases)/(*I*<sub>P</sub>) Pickup currents 51N (ground)/(IEp) Time multiplier T for 51, 51N 0.05 to 3.2 s or  $\infty$  (in steps of 0.01 s) (IP, IEP) (IEC characteristics) Time multiplier D for 51, 51N 0.50 to 15 s or  $\infty$  (in steps of 0.01 s) (ANSI characteristics) Trip characteristics Inverse (type A), very inverse (type B), IEC acc. to IEC 60255-3 or BS 142 extremely inverse (type C), long inverse (type B) ANSI/IEEE Inverse, short inverse, long inverse, moderately inverse, very inverse,

Dropout characteristics with disk emulation	
IEC acc. to IEC 60255-3 or BS 142	Inverse (type A), very inverse (type B), extremely inverse (type C), long inverse (type B)
ANSI/IEEE	Inverse, short inverse, long inverse, moderately inverse, very inverse, extremely inverse, definite inverse
Pickup threshold IEC and ANSI	Approx. 1.1 $\cdot I_p$
Dropout setting IEC and ANSI Without disk emulation With disk emulation	Approx. 1.05 $\cdot$ $I_{\rm p}$ setting value for $I_p/I_{\rm nom} \ge 0.3$ , corresponds to approx. 0.95 $\cdot$ pickup value Approx. 0.9 $\cdot$ $I_{\rm p}$ setting value
Tolerances	rippiox. 0.9 ip setting value
Pickup/dropout thresholds $I_p$ , $I_{Ep}$ Trip time for $2 \le l/I_p \le 20$	3 % of setting value or 75 mA <sup>1)</sup> 5 % of reference (calculated) value + 2 % current tolerance or 30 ms
Dropout time for $I/I_p \le 0.9$	5 % of reference (calculated) value + 2 % current tolerance or 30 ms
Determination of direction	
For phase faults	
Polarization/type	With cross-polarized voltages With voltage memory (memory depth 2 seconds) for measurement voltages that are too low
Forward range Rotation of reference voltage $V_{ m ref,rot}$	$V_{\text{ref,rot}} \pm 86^{\circ}$ -180° to 180° (in steps of 1°)
Directional sensitivity	For one and two-phase faults unlimited For three-phase faults dynamically unlimited Steady-state approx. 7 V phase-to-phase
For ground faults	
Polarization/type	With zero-sequence quantities
	$3V_0$ , $3I_0$ or with negative-sequence quantities $3V_2$ , $3I_2$
Forward range Rotation of reference voltage $V_{\rm ref,rot}$	$V_{\text{ref,rot}} \pm 86^{\circ} -180^{\circ} \text{ to } 180^{\circ} \text{ (in steps of 1 °)}$
Directional sensitivity Zero-sequence quantities $3V_0$ , $3I_0$	$V_{\rm N} \approx 2.5 \text{ V}$ displacement voltage, measured $3V_0 \approx 5 \text{ V}$ displacement voltage,
Negative-sequence quantities $3V_2$ , $3I_2$	calculated $3V_2 \approx 5$ V negative-sequence voltage $3I_2 \approx 225$ mA negative-sequence current <sup>1)</sup>
Times Pickup times (without inrush restraint; with inrush restraint + 10 ms) 50-1, 50-2, 50N-1, 50N-2 With twice the setting value With ten times the setting value	Approx. 45 ms Approx. 40 ms
Dropout time 50-1, 50-2, 50N-1, 50N-2	Approx. 40 ms
Tolerances Angle faults for phase and earth faults	± 3 ° electrical

extremely inverse, definite inverse

Inrush restraint	
Controlled functions	Time-overcurrent elements, $I$ >, $I_E$ >, $I_p$ , $I_{Ep}$ (directional, non-directional) 50-1, 50N-1, 51, 51N, 67-1, 67N-1
Lower function limit	At least one phase current (50 Hz and 100 Hz) $\geq$ 125 mA for $I_{nom} = 5$ A, $\geq$ 50 mA for $I_{nom} = 1$ A
Upper function limit (setting range)	1.5 to 125 A <sup>1)</sup> (in steps of 0.01 A)
Setting range, stabilization factor $I_{2f}/I$	10 to 45 % (in steps of 1 %)
Crossblock $I_{A(L1)}$ , $I_{B(L2)}$ , $I_{C(L3)}$	ON/OFF
Cold-load pickup/dynamic setting c	hange
Controllable functions	Directional and non-directional time-overcurrent protection (separated acc. to phases and ground)
Initiation criteria	Current criterion "BkrClosed/MIN" CB position via aux. contacts, binary input, auto-reclosure ready
Time control	3 time elements $(T_{CB \text{ Open}}, T_{\text{Active}}, T_{\text{Stop}})$
Current control	Current threshold "BkrClosed/MIN" (reset on dropping below threshold; monitoring with timer)
Setting ranges Current control Time until changeover to dynamic setting $T_{CB Open}$	0.2 to 5 A <sup>1)</sup> (in steps of 0.01 A) 0 to 21600 s (= 6 h) (in steps of 1 s)
Period dynamic settings are effective after a reclosure $T_{\text{Active}}$	1 to 21600 s (= 6 h) (in steps of 1 s)
Fast reset time $T_{\text{Stop}}$	1 to 600 s (= 10 min.) or $\infty$ (fast reset inactive) (in steps of 1 s)
Dynamic settings or pickup currents and time delays or time multipliers	Adjustable within the same ranges and with the same steps (increments) as the directional and non-directional time-overcurrent protection
Single-phase overcurrent protection	1
Current elements	
High-set current elements 50-2 ( <i>I</i> >>)	0.005 to 8 A (in steps of 0.001 A) or $\infty^{(1)}$ (disabled)
Definite-time current element 50-1 ( <i>I</i> >)	0.005 to 8 A or $\infty^{1}$ (disabled) (in steps of 0.001 A)
$T_{50-1}, T_{50-2}$ $(T_1 > / T_1 >>)$	0 to 60 s or $\infty$ (no trip) (in steps of 0.01 s)
Operating times Minimum Typical	14 ms 30 ms
Dropout time	Approx. 25 ms
Dropout ratios Current elements	Approx. 0.95 for $I/I_{\rm nom} \ge 0.5$
Tolerances	
Currents	5 % of setting value or 1 mA
Times	1 % of setting value or 10 ms
Voltage protection (ANSI 27, 59)	
Undervoltages 27-1, 27-2 (V<, V<<)	
Measured quantity used with Three-phase connection	Positive-sequence system of the voltages Lowest phase-to-phase voltage Lowest phase-to-ground voltage
Single-phase connection	Connected single-phase-to-ground

Single-phase connection Connected single-phase-to-ground voltage

1) At  $I_{\text{nom}} = 1$  A, all limits divided by 5. 2)  $r = V_{\text{dropout}}/V_{\text{pickup}}$ .

Setting ranges Connection of phase-to-ground voltage	10 to 120 V (in steps of 1 V)
Connection of phase-to-phase voltage	10 to 120 V (in steps of 1 V)
Connection of single phase Dropout ratio <sup>2)</sup> $r$ for 27-1, 27-2 (V<, V<<)	10 to 120 V (in steps of 1 V) 1.01 to 3 (in steps of 0.01)
Dropout threshold for $r \cdot 27-1 (V <)$ $r \cdot 27-2 (V <<)$	Max. 130 V for phase-to-phase voltage Max. 225 V for phase-to-ground volt.
Hysteresis	Min. 0.6 V
Time delays <i>T</i> 27-1( <i>V</i> <), <i>T</i> 27-2 ( <i>V</i> <<)	0 to 100 s (in steps of 0.01 s) or $\infty$ (disabled)
Current criterion "BkrClosed/MIN"	0.2 to 5 $A^{11}$ (in steps of 0.01 A)
<b>Overvoltages</b> 59-1, 59-2 (V>, V>>)	
Measured quantity used with Three-phase connection	Positive-sequence system of the voltages Negative-sequence system of the volt- ages Highest phase-to-phase voltage Highest phase-to-ground voltage
Single-phase connection	Connected single-phase-to-ground voltage
Setting ranges Connection of phase-to-ground voltage:	
Evaluation of phase-to-ground voltages	20 to 150 V (in steps of 1 V)
Evaluation of phase-to-phase voltages	20 to 260 V (in steps of 1 V)
Evaluation of positive-sequence system	20 to 150 V (in steps of 1 V)
Evaluation of negative-sequence system	2 to 150 V (in steps of 1 V)
Connection of phase-to-phase voltages:	
Evaluation of phase-to-phase voltage	20 to 150 V (in steps of 1 V)
Evaluation of positive-sequence system	20 to 150 V (in steps of 1 V)
Évaluation of negative-sequence system	2 to 150 V (in steps of 1 V)
Connection single phase Dropout ratio <i>r</i>	20 to 150 V (in steps of 1 V)
for 59-1, 59-2 (V>, V>>)	0.90 to 0.99 (in steps of 0.01 V)
Dropout threshold for $r \cdot 59-1$ (V>) $r \cdot 59-2$ (V>>)	Max. 150 V for phase-to-phase voltage Max. 260 V for phase-to-ground volt.
Hysteresis	Min. 0.6 V
Time delay <i>T</i> 59-1, <i>T</i> 59-2 ( <i>V</i> >, <i>V</i> >>)	0 to 100 s (in steps of 0.01 s) or $\infty$ (disabled)
Times Pickup times Undervoltage 27-1, 27-2 (V<, V<<)	Approx 50 mg
27-1 <i>V</i> <sub>1</sub> , 27-2 <i>V</i> <sub>1</sub> Overvoltage 59-1, 59-2 ( <i>V</i> >, <i>V</i> >>) Overvoltage 59-1 <i>V</i> <sub>1</sub> , 59-2 <i>V</i> <sub>1</sub> ,	Approx. 50 ms Approx. 50 ms
59-1 V <sub>2</sub> , 59-2 V <sub>2</sub>	Approx. 60 ms
Dropout times Undervoltage 27-1,27-2 (V<, V<<) 27-1 V1, 27-2 V1 Overvoltage 59, 1, 59, 2 (IC) IC>)	Approx. 50 ms
Overvoltage 59-1, 59-2 ( <i>V</i> >, <i>V</i> >>) Overvoltage 59-1 <i>V</i> <sub>1</sub> , 59-2 <i>V</i> <sub>1</sub> , 59-1 <i>V</i> <sub>2</sub> , 59-2 <i>V</i> <sub>2</sub>	
Tolerances	Approx. 60 ms
Pickup voltage limits Delay times T	3 % of setting value or 1 V 1 % of setting value or 10 ms
ıly 2010	Technical Data page 5

#### Negative-sequence protection (ANSI 46) Definite-time characteristic (ANSI 46-1 and 46-2) Setting ranges Unbalanced load tripping element 0.5 to 15 A or $\infty$ (disabled)<sup>1)</sup> 46-1, 46-2 (I<sub>2</sub>>, I<sub>2</sub>>>) (in steps of 0.01 A) Delay times 46-1, 46-2 (*T*<sub>I2</sub>>, *T*<sub>I2</sub>>>) 0 to 60 s or $\infty$ (disabled)<sup>1)</sup> (in steps of 0.01 s)

Dropout delay times 46 T<sub>Dropout</sub> Functional limit Times Pickup times

Dropout times Dropout ratio Characteristic 46-1, 46-2/*I*<sub>2</sub>>, *I*<sub>2</sub>>>

Tolerances Pickup values 46-1, 46-2/I<sub>2</sub>>, I<sub>2</sub>>> Delay times

## 3 % of the set value or 75 mA<sup>1)</sup> 1 % or 10 ms

Approx. 0.95 for  $I_2/I_{\text{nom}} \ge 0.3$ 

0 to 60 s (in steps of 0.01 s)

All phase currents  $\leq 50 \text{ A}^{1}$ 

Approx. 35 ms Approx. 35 ms

Inverse-time characteristic (ANSI 46-TOC)

Setting ranges Pickup value 46-TOC/I2p Time multiplier  $T_{I2p}$  (IEC)

Time multiplier D<sub>I2p</sub> (ANSI)

Functional limit Trip characteristics acc. to IEC

ANSI

Pickup threshold IEC and ANSI Tolerances Pickup threshold I2p Time for  $2 \le I/I_{2p} \le 20$ 

Dropout characteristic with disk emulation acc. to ANSI

Dropout value IEC and ANSI without disk emulation ANSI with disk emulation

Tolerances Dropout value I2p Time for  $2 \le I_2/I_{2p} \le 0.90$ 

#### Frequency protection (ANSI 810/U)

Number of frequency elements Setting ranges Pickup values f > or f< for  $f_{\rm nom} = 50$  Hz Pickup values f > or f <for  $f_{\rm nom} = 60 \, \text{Hz}$ 

Delay times T

Undervoltage blocking, with positive-sequence voltage V1

1) At  $I_{nom} = 1$  A, all limits divided by 5.

0.5 to 10 A<sup>1)</sup> (in steps of 0.01 A) 0.05 to 3.2 s or  $\infty$  (disabled) (in steps of 0.01 s) 0.5 to 15 s or  $\infty$  (disabled) (in steps of 0.01 s) All phase currents  $\leq 50 \text{ A}^{1)}$ 

Inverse, very inverse, extremely inverse Inverse, moderately inverse, very inverse, extremely inverse Approx.  $1.10 \cdot I_{2p}$ 

3 % of the setting value or 75 mA<sup>1)</sup> 5 % of reference (calculated) value

+ 2 % current tolerance or 30 ms Inverse, moderately inverse,

very inverse, extremely inverse

Approx.  $1.05 \cdot I_{2p}$  setting value, corresponds to approx. 0.95 · pickup Approx.  $0.90 \cdot I_{2p}$  setting value

3 % of the set value or 75 mA<sup>1)</sup> 5 % of reference (calculated) value +2 % current tolerance, or 30 ms

4, each can be set to f > or f <

40 to 60 Hz (in steps of 0.01 Hz) 50 to 70 Hz (in steps of 0.01 Hz)

0 to 100 s or  $\infty$  (disabled) (in steps of 0.01 s) 10 to 150 V (in steps of 1 V)

Times Pickup times <i>f</i> >, <i>f</i> < Dropout times <i>f</i> >, <i>f</i> <	Approx. 80 ms Approx. 80 ms
Dropout difference $\Delta f =  \text{pickup value} - \text{dropout value} $	
Dropout Ratio undervoltage blocking	Approx. 1.05
Tolerances Pickup thresholds Frequency 81O/U <i>f</i> >, <i>f</i> < Undervoltage blocking Delay times	15 mHz (with $V = V_{\text{nom}}, f = f_{\text{nom}}$ ) 3 % of setting value or 1 V 1 % of the setting value or 10 ms
Thermal overload protection (ANSI	19)
Setting ranges	
Factor k	0.1 to 4 (in steps of 0.01)
Time constant	1 to 999.9 min (in steps of 0.1 min)
Current warning stage I <sub>Alarm</sub>	0.5 to 20 A (in steps of 0.01 A)
Extension factor when stopped $k_r$ factor	1 to 10 with reference to the time constant with the machine running (in steps of 0.1)
$\begin{array}{l} \text{Dropout ratios} \\ \Theta / \Theta_{\text{Trip}} \\ \Theta / \Theta_{\text{Alarm}} \\ I / I_{\text{Alarm}} \end{array}$	Drops out with $\Theta_{Alarm}$ Approx. 0.99 Approx. 0.97
Tolerances With reference to $\mathbf{k} \cdot I_{nom}$	3 % or 75 mA <sup>1)</sup> 2 % class acc. to IEC 60255-8
With reference to tripping time	3 % or 1 s for $I/(k \cdot I_{nom}) > 1.25$ 3 % class acc. to IEC 60255-8
(Sensitive) ground-fault protection (	ANSI 59N/64, 50Ns, 51Ns, 67Ns)
Displacement voltage element for a	ll types of ground fault (ANSI 59N/64)
Setting ranges Displacement voltage (measured) Displacement voltage (calculated) Delay time T <sub>Delay</sub> pickup Additional trip delay T <sub>V Delay</sub>	$V_0$ > 1.8 to 200 V (in steps of 0.1 V) $3V_0$ > 10 to 225 V (in steps of 0.1 V) 0.04 to 320 s or ∞ (in steps of 0.01 s) 0.1 to 40,000 s or ∞ (in steps of 0.01 s)
Operating time	Approx. 50 ms
Dropout ratio	0.95 or (pickup value –0.6 V)
Tolerances (measurement) Pickup threshold $V_0$ (measured) Pickup threshold $3V_0$ (calculated) Delay times	3 % of setting value or 0.3 V 3 % of setting value or 3 V 1 % of setting value or 10 ms
Phase detection for ground fault in	an ungrounded system
Measuring principle	Voltage measurement (phase-to-ground)
Setting ranges $V_{\rm phmin}$ (ground-fault phase)	10 to 100 V (in steps of 1 V)

V<sub>ph max</sub> (healthy phases) Tolerance Measurement tolerance acc. to VDE 0435, Part 303 10 to 100 V (in steps of 1 V) 3 % of setting value or 1 V

(Sensitive) ground-fault protection (	ANSI 59N/64, 50Ns, 51Ns, 67Ns) (cont'd)	Measuring method " $\varphi$ ( $V_0/I_0$ )"	
Ground-fault pickup for all types of ground faults		Direction measurement	$I_{\rm N}$ and $V_{\rm N}$ measured or
Definite-time characteristic (ANSI 5			$3I_0$ and $3V_0$ calculated
Setting ranges Pickup current 50Ns-2 Pickup, 50Ns-1 Pickup; ( <i>I</i> <sub>EE</sub> >, <i>I</i> <sub>EE</sub> >>) For sensitive 5-A-transformer For normal 5-A-transformer Delay times <i>T</i> for 50Ns-2 Delay,	0.005 to 8 A <sup>1)</sup> (in steps of 0.005 A) 0.25 to 175 A <sup>1)</sup> (in steps of 0.05 A) 0 to 320 s $\infty$ (disabled)	Minimum voltage $V_{\min}$ . $V_0$ measured $3V_0$ calculated Phase angle 50Ns $\varphi$ Delta phase angle 50Ns $\Delta \varphi$ <b>Angle correction for cable CT</b>	0.4 to 50 V (in steps of 0.1 V) 10 to 90 V (in steps of 1 V) –180 ° to 180 ° (in steps of 0.1 °) 0 ° to 180 ° (in steps of 0.1 °)
50Ns-1 Delay ( $T_{\text{IEE}}$ , $T_{\text{IEE}}$ )) Dropout delay time $T_{\text{Dropout}}$	(in steps of 0.01 A) 0 to 60 s (in steps of 0.01 s)	Angle correction F1, F2 (for resonant grounded system)	0 ° to 5 ° (in steps of 0.1 °)
Operating times	$\leq$ 50 ms (directional/non-directional)	Current value $I_1$ , $I_2$ for angle	
Dropout ratio	Approx. 0.95 for $50 \text{Ns}/I_{\text{EE}} > 50 \text{ mA}$	correction	
Tolerances (measurement) Pickup threshold For sensitive 5-A-transformer	3 % of setting value or 5 mA <sup>1)</sup> Approx. 20 % for setting values < 10 mA	For sensitive 5-A-transformer For normal 5-A-transformer Tolerances For sensitive 5-A-transformer	0.005 to 8 A <sup>1)</sup> (in steps of 0.005 A) 0.25 to 175 A <sup>1)</sup> (in steps of 0.05 A) 3 % of setting value or 5 mA <sup>1)</sup>
For normal 5-A-transformer Delay times	3 % of setting value or 75 mA <sup>1)</sup> 1 % of setting value or 10 ms	For normal 5-A-transformer	Approx. 20 % for setting values < 10 mA 3 % of setting value or 75 mA <sup>1)</sup> 3 °
Ground-fault pickup for all types of	5	Angle tolerance	0
Inverse-time characteristic (ANSI 51	Ns)		e linear range of the measuring input input transformer is from $0.001 \cdot I_{nom}$
User-defined characteristic	Defined by a maximum of 20 pairs of current and delay time values, directional measurement method	to $1.6 \cdot I_{nom}$ . For currents great determination can no longer	ter than $1.6 \cdot I_{nom}$ correct direction
	"cos phi and sin phi"	Auto-reclosure (ANSI 79)	
Setting ranges		Number of reclosures	0 to 9
Pickup current 51Ns; $I_{EEp}$ For sensitive 5-A-transformer For normal 5-A-transformer Time multiplier $T_{51Ns}$ , $I_{IEEp}$	0.005 A to 7 $A^{11}$ (in steps of 0.005 A) 0.25 to 20 $A^{11}$ (in steps of 0.05 A) 0.1 to 4 s or $\infty$ (disabled) (in steps of 0.01 s)	Program for phase fault Start-up by	Shot 1 to 4 individually adjustable Time-overcurrent elements (directional/non-directional), negative sequence, binary input
Pickup threshold	Approx. $1.1 \cdot I_{51Ns}/1.1 \cdot I_{EEp}$	Program for ground fault	
Dropout ratio	Approx. $1.05 \cdot I_{51Ns}/1.05 \cdot I_{EEp}$ for $I_{51Ns}$ ( $I_{EEp}$ ) > 50 mA	Start-up by	Time-overcurrent elements (directional/non-directional), sensitive ground-fault protection,
Tolerances For sensitive 5-A-transformer For normal 5-A-transformer Operating time tolerance in linear range	3 % of setting value or 5 mA <sup>1)</sup> Approx. 20 % for setting values < 10 mA 3 % of setting value or 75 mA <sup>1)</sup> 7 % of reference (calculated) value for 2 $\leq I/I_{51Ns}$ ( $I_{EEp}$ ) $\leq$ 20 + 2 % cur- rent tolerance, or 70 ms	Blocking of ARC	binary input Pickup of protection functions, three-phase fault detected by a protective element (optional), binary input, last TRIP command after the reclosing cycle is completed (unsuccessful reclosing),
Direction determination for all type	s of ground-faults (ANSI 67Ns)		TRIP command by the breaker
Measuring method " $\cos \varphi / \sin \varphi$ "			failure protection (50BF),
Direction measurement	$I_{ m N}$ and $V_{ m N}$ measured or $3I_0$ and $3V_0$ calculated		opening the CB without ARC initia- tion, external CLOSE command, circuit-breaker monitoring
Measuring principle	Active/reactive power measurement	Setting ranges	-
Setting ranges Measuring enable <i>I</i> <sub>Release direct</sub> . (current component perpendicu-		Dead time $T_{\text{Dead}}$ (separate for phase and ground and individual for shots 1 to 4)	0.01 to 320 s (in steps of 0.01 s)
lar (90 °) to directional limit line) For sensitive 5-A-transformer For normal 5-A-transformer	0.005 to 8 A <sup>1)</sup> (in steps of 0.005 A) 0.25 to 175 A <sup>1)</sup> (in steps of 0.05 A)	Blocking duration for manual- CLOSE detection	0.5  s to  320  s or  0  (in steps of  0.01  s)
Dropout ratio	Approx. 0.8	Blocking duration after reclosure Blocking duration after dynamic blocking	0.5 s to 320 s (in steps of 0.01 s) 0.01 to 320 s (in steps of 0.01 s)
Direction phasor $\varphi_{\text{Correction}}$	-45 ° to $+45$ ° (in steps of 0.1 °)	Start-signal monitoring time	0.01 to 320 s or $\infty$ (in steps of 0.01 s)
Dropout delay T <sub>Reset delay</sub>	1 to 60 s (in steps of 1 s)	Circuit-breaker monitoring time	0.1 to 320 s (in steps of 0.01 s)
		Max. delay of dead-time start	0 to 1800 s or $\infty$ (in steps of 0.1 s)
		Start delay of dead time	Using binary input with time moni- toring
	nd fault detection is from 0.001 A to	Maximum dead time extension Action time (operation time)	0.5 to 320 s or $\infty$ (in steps of 0.01 s) 0.01 to 320 s or $\infty$ (in steps of 0.01 s)
1.0 A OF 0.005 A to 8 A. 1 ne fur	nction is however still preserved for		(

1.6 A or 0.005 A to 8 A. The function is however still preserved for higher currents.

1) At  $I_{nom} = 1$  A, all limits divided by 5.

Auto-reclosure (ANSI 79) (con'd) The delay times of the following protection function can be altered individually by the ARC for shots 1 to 4 (setting value: T = T; non-delayed: T = 0; blocking:  $T = \infty$ ): 50-1, 50-2, 50-3, 51, 67-1, 67-2, 67-TOC, 50N-1, 50N-2, 50N-3, 51N, 67N-1, 67-N-2, 67N-TOC Additional functions Lockout (final trip), circuit-breaker monitoring, evaluation of the CB contacts, synchronous closing (optionally with integrated or external synch-check) Fault locator (ANSI 21FL) Output of the fault distance in  $\Omega$  primary and secondary, in km or miles line length, in % of line length Trip command, dropout of a Starting signal, trigger protection element, or external command via binary input Setting ranges 0.001 to  $1.9 \,\Omega/\text{km}^{2)}$  (in steps of 0.0001) 0.001 to  $3 \,\Omega/\text{mile}^{2)}$  (in steps of 0.0001) Reactance (secondary) Tolerances 2.5 % fault location Measurement tolerance acc. to VDE 0435, Part 303 for sinusoidal (without intermediate infeed) for 30 °  $\leq \varphi_{\rm K} \leq$  90 ° and  $V_{\rm K}/V_{\rm nom} \geq 0.1$ measurement quantities and  $I_{\rm K}/I_{\rm nom} \geq 1$ Breaker failure protection (ANSI 50BF) Setting ranges 0.25 to 100 A<sup>1)</sup> (in steps of 0.01 A) Pickup thresholds 0.06 to 60 s or  $\infty$  (in steps of 0.01 s) Delay time Times Pickup times with internal start is included in the delay time with external start is included in the delay time Dropout times Approx. 25 ms Tolerances Pickup thresholds 3 % of setting value or 75 mA1) Delay time 1 % or 20 ms Flexible protection functions (e.g. ANSI 27, 32, 37, 47, 50, 55, 59, 81R) Operating modes/measuring quantities I, I1, I2, I2/I1, 3I0, V, V1, V2, 3V0, 3-phase  $P_{ ext{forward}}, P_{ ext{reverse}}, Q_{ ext{forward}}, Q_{ ext{reverse}}, \cos arphi$  $I, I_{\rm N}, I_{\rm NS}, I_{\rm N2}, V, V_{\rm N}, V_x$ 1-phase  $P_{\text{forward}}, P_{\text{reverse}}, Q_{\text{forward}}, Q_{\text{reverse}}, \cos \varphi$ Without fixed phase relation *f*, d*f*/d*t*, binary input Exceeding or falling below threshold Pickup when value Setting ranges Pickup thresholds 0.25 to 200 A<sup>1)</sup> (in steps of 0.01 A) Current I, I1, I2, 3I0, IN Current ratio  $I_2/I_1$ 15 to 100 % (in steps of 1 %) 0.001 to 1.5 A (in steps of 0.001 A) Sensitive ground current INS Voltages  $V, V_1, V_2, 3V_0$ 2 to 260 V (in steps of 0.1 V) Displacement voltage V<sub>N</sub> 2 to 200 V (in steps of 0.1 V)

Setting ranges, continued 10 to 50000 W<sup>1)</sup> (in steps of 0.1 W) Power P, O -0.99 to +0.99 (in steps of 0.01) Power factor  $(\cos \varphi)$ 40 to 60 Hz (in steps of 0.01 Hz) Frequency  $f_N = 50$  Hz  $f_{\rm N} = 60 \text{ Hz}$ 50 to 70 Hz (in steps of 0.01 Hz) Rate-of-frequency change df/dt 0.1 to 20 Hz/s (in steps of 0.01 Hz/s) Dropout ratio >- element 1.01 to 3 (insteps of 0.01) Dropout ratio <- element 0.7 to 0.99 (in steps of 0.01) Dropout difference f 0.02 to 1 Hz (in steps of 0.01 Hz) Pickup delay time (standard) 0 to 60 s (in steps of 0.01 s) Pickup delay for  $I_2/I_1$ 0 to 28800 s (in steps of 0.01 s) Trip delay time 0 to 3600 s (in steps of 0.01 s) Dropout delay time 0 to 60 s (in steps of 0.01 s) Times Pickup times Current, voltage (phase quantities) Approx. 30 ms With 2 times the setting value With 10 times the setting value Approx. 20 ms Current, voltages (symmetrical components) With 2 times the setting value Approx. 40 ms With 10 times the setting value Approx. 30 ms Power Approx. 120 ms Typical Maximum (low signals and Approx. 350 ms thresholds) 300 to 600 ms Power factor Approx. 100 ms Frequency Rate-of-frequency change With 1.25 times the setting value Approx. 220 ms Binary input Approx. 20 ms Dropout times Current, voltage (phase < 20 ms quantities) Current, voltages (symmetrical < 30 ms components) Power Typical < 50 ms Maximum < 350 ms Power factor < 300 ms Frequency < 100 ms Rate-of-frequency change < 200 ms Binary input < 10 msTolerances Pickup thresholds 3 % of setting value or 75 mA11 Current Current (symmetrical 4 % of setting value or 100 mA<sup>1)</sup> components) Voltage 3 % of setting value or 0.2 V Voltage (symmetrical 4 % of setting value or 0.2 V components) Power 3 % of setting value or 2.5 W<sup>1)</sup> Power factor (for rated values) 3 degrees Frequency 15 mHz Rate-of-frequency change 5 % of setting value or 0.05 Hz/s Times 1 % of setting value or 10 ms

At *I*<sub>nom</sub> = 1 A, all limits divided by 5.
 At *I*<sub>nom</sub> = 1 A, setting range to be multiplied by 5.

Synch-check (ANSI 25) Operating mode Additional release conditions

Voltages Max. operating voltage Vmax

Min. operating voltage Vmin

V< for dead-line

V> for live-line

Primary rated voltage of transformer V2nom Tolerances Dropout ratios

Permissible differences Voltage difference V2> V1; V2< V1 Tolerance Frequency differences

(f2>f1; f2<f1)Tolerance

Angle differences  $\alpha 2 > \alpha 1 : \alpha 2 < \alpha 1$ Tolerance Max. phase displacement

Vector group matching by angle Different voltage transformers  $V_{1}/V_{2}$ 

Times Minimum measuring time Max. duration T<sub>SYN</sub> DURATION Supervision time  $T_{SUP VOLTAGE}$ Tolerance of all times

Measuring values of synch-check function

Reference voltage V1 and voltage to be synchronized V2 Range Tolerance\*)

Frequency of voltage V1 and V2 Range Tolerance\*) Voltage difference (V2 - V1)

Range Tolerance\*)

Frequency difference  $(f_2 - f_1)$ Range Tolerance\*) Angle difference  $(\alpha 2 - \alpha 1)$ Range Tolerance\*)

#### • Synch-check

- Live-bus / dead line
- Dead-bus / live-line
- Dead-bus and dead-line • Bypassing

20 to 140 V (phase-to-phase) (in steps of 1 V) 20 to 125 V (phase-to-phase) (in steps of 1 V) 1 to 60 V (phase-to-phase) (in steps of 1 V) 20 to 140 V (phase-to-phase) (in steps of 1 V) 0.1 to 800 kV (in steps of 0.01 kV)

2 % of pickup value or 2 V Approx. 0.9 (V>) or 1.1 (V<)

0.5 to 50 V (phase-to-phase) (in steps of 1 V) 1 V

0.01 to 2 Hz (in steps of 0.01 Hz) 30 mHz 2 ° to 80 ° (in steps of 1 °)

2° 5° for  $\Delta f \leq 1$  Hz 10 ° for  $\Delta f \leq 1$  Hz 0 ° to 360 ° (in steps of 1 °) 0.5 to 2 (in steps of 0.01)

Approx. 80 ms 0.01 to 1200 s;  $\infty$  (in steps of 0.01 s) 0 to 60 s (in steps of 0.01 s) 1 % of setting value or 10 ms

In kV primary, in V secondary or in % V<sub>nom</sub> 10 to 120 % of Vnom  $\leq$  1 % of measured value or 0.5 % of  $V_{\rm nom}$ f1, f2 in Hz  $25 \text{ Hz} \le f \le 70 \text{ Hz}$ 20 mHz In kV primary, in V secondary or in % V<sub>nom</sub> 10 to 120 % V<sub>nom</sub>  $\leq$  1 % of measured value or 0.5 % of Vnom In mHz  $f_{\rm nom} \pm 3 \text{ Hz}$ 30 mHz In ° 0 to 180 ° 1 °

#### Additional functions

#### **Operational measured values**

Currents  $I_{A(L1)}, I_{B(L2)}, I_{C(L3)}$ Positive-sequence component I1 Negative-sequence component I2  $I_{\rm E}$  or  $3I_0$ Range

Tolerance\*)

#### Voltages Phase-to-ground voltages $V_{\text{A-N}}$ , $V_{\text{B-N}}$ , $V_{\text{C-N}}$ Phase-to-phase voltages V<sub>A-B</sub>, V<sub>B-C</sub>, V<sub>C-A</sub>, V<sub>SYN</sub> $V_{\rm N}$ , $V_{\rm ph-N}$ , $V_{\rm x}$ or $V_0$ Positive-sequence component $V_1$ Negative-sequence component V2 Range

Tolerance\*)

S, apparent power

Range Tolerance\*)

P, active power

Range Tolerance\*)

Q, reactive power

Range Tolerance\*)

 $\cos \varphi$ , power factor (p.f.) Range Tolerance\*)

Frequency f

Range Tolerance\*) Temperature overload protection  $\Theta/\Theta_{\rm Trin}$ Range Tolerance\*) Currents of sensitive ground-fault

detection (total, active, and reactive current) I<sub>Ns</sub>, I<sub>Ns active</sub>, I<sub>Ns reactive</sub>;  $(I_{\text{EE}}, I_{\text{EE active}}, I_{\text{EE reactive}})$ Range Tolerance\*)

\*) With rated frequency.

1) At  $I_{nom} = 1$  A, all limits divided by 5.

In A (kA) primary, in A secondary or in % Inom

10 to 150 % Inom 1.5 % of measured value or 1 % Inom and from 151 to 200 % Inom 3 % of measured value

In kV primary, in V secondary or in % Vnom

10 to 120 % of V<sub>nom</sub> 1.5 % of measured value or 0.5 % of V<sub>nom</sub> In kVAr (MVAr or GVAr) primary and in % of Snom

0 to 120 % of Snom 1.5 % of Snom for  $V/V_{\text{nom}}$  and  $I/I_{\text{nom}} = 50$  to 120 %

With sign, total and phasesegregated in kW (MW or GW) primary and in % Snom

0 to 120 % of Snom 2 % of Snom for  $V/V_{\text{nom}}$  and  $I/I_{\text{nom}} = 50$  to 120 % and  $|\cos \varphi| = 0.707$  to 1 with  $S_{\text{nom}} = \sqrt{3} \cdot V_{\text{nom}} \cdot I_{\text{nom}}$ 

With sign, total and phasesegregated in kVAr (MVAr or GVAr) primary and in % of Snom

0 to 120 % of Snom 2 % of S<sub>nom</sub> for  $V/V_{nom}$  and  $I/I_{nom} = 50$  to 120 % and  $|\sin \varphi| = 0.707$  to 1 with  $S_{\text{nom}} = \sqrt{3} \cdot V_{\text{nom}} \cdot I_{\text{nom}}$ 

Total and phase-segregated -1 to +1

2 % for  $|\cos \varphi| \ge 0.707$ In Hz

 $f_{\rm nom} \pm 5 \, \text{Hz}$  $20 \,\mathrm{mHz}$ In %

0 to 400 % 5 % class accuracy per IEC 60255-8 In A (kA) primary and in mA secondary

0 mA to 8000 mA for  $I_{nom} = 5 \text{ A}^{(1)}$ 3 % of measured value or 1 mA

reennearaata		
Long-term averages		Oscillograp
Time window	5, 15, 30 or 60 minutes	Maximum 8
Frequency of updates	Adjustable	memory mail in case of los
Long-term averages		Recording ti
of currents of active power	I <sub>Admd</sub> , I <sub>Bdmd</sub> , I <sub>Cdmd</sub> (I <sub>L1dmd</sub> , I <sub>L2dmd</sub> , I <sub>L3dmd</sub> ) I <sub>1dmd</sub> in A (kA) P <sub>dmd</sub> in W (kW, MW)	Sampling rat Sampling rat
of reactive power	Q <sub>dmd</sub> in VAr (kVAr, MVAr)	Energy/pow
of apparent power	S <sub>dmd</sub> in VAr (kVAr, MVAr)	Meter values
Max. / Min. report	With date and time	Wp, Wq
Report of measured values Reset, automatic	Time of day adjustable (in minutes,	(active and r Tolerance*)
Reset, automatic	0 to 1439 min) Time frame and starting time adjust-	Statistics
	able (in days, 1 to 365 days, and $\infty$ )	Saved numb
Reset, manual	Using binary input, using keypad, via communication	Number of a commands ( to $1^{st}$ and $\geq$
Min./Max. values for current	$I_{A(L1)}, I_{B(L2)}, I_{C(L3)}$ $I_1$ (positive-sequence component)	Accumulated
Min./Max. values for voltages	V <sub>A-N</sub> , V <sub>B-N</sub> , V <sub>C-N</sub> (V <sub>L1-E</sub> , V <sub>L2-E</sub> , V <sub>L3-E</sub> ) V <sub>1</sub> (positive-sequence component)	(segregated a <b>Operating h</b>
	V <sub>A-B</sub> , V <sub>B-C</sub> , V <sub>C-A</sub> (V <sub>L1-L2</sub> , V <sub>L2-L3</sub> , V <sub>L3-L1</sub> )	Display rang Criterion
Min./Max. values for power	S, P, Q, $\cos \varphi$ , frequency	
Min./Max. values for overload protection	$\Theta/\Theta_{\mathrm{Trip}}$	Circuit-brea
Min./Max. values for mean values	IAdmd, IBdmd, ICdmd (IL1dmd, IL2dmd,	Calculation
	I <sub>L3dmd</sub> ) I <sub>1</sub> (positive-sequence component); S <sub>dmd</sub> , P <sub>dmd</sub> , Q <sub>dmd</sub>	
Local measured values monitoring		Measured-va
Current asymmetry	<i>I</i> <sub>max</sub> / <i>I</i> <sub>min</sub> > balance factor, for <i>I</i> > <i>I</i> <sub>balance limit</sub>	processing Evaluation
Voltage asymmetry	$V_{\text{max}}/V_{\text{min}}$ > balance factor,	Saved numb
Current sum	for $V > V_{\text{lim}}$ $ i_A + i_B + i_C + k_J \cdot i_N  > \text{limit value}$	Trip circuit r
Current sum		With one or
Current phase sequence	Clockwise (ABC) / counter-clockwise (ACB)	Commission
Voltage phase sequence	Clockwise (ABC) / counter-clockwise (ACB)	Phase rotatio operational r circuit-break
Fault event recording		of control fu
Recording of indications of the last 8 power system faults		creation of a creation of m
Recording of indications of the last 3 power system ground faults		Clock Time synchr
Time stamping		
Resolution for event log	1 ms	Setting grou
(operational annunciations) Resolution for trip log	1 ms	Number of a Switchover p
(fault annunciations) Maximum time deviation	0.01 %	
(internal clock)		
Battery	Lithium battery 3 V/1 Ah, type CR 1/2 AA, message "Battery Fault" for insufficient battery charge	

#### hic fault recording 8 fault records saved, aintained by buffer battery oss of power supply 5 s per fault record, in total up to 18 s ime ate for 50 Hz 1 sample/1.00 ms ate for 60 Hz 1 sample/0.83 ms ver es for power in kWh (MWh or GWh) and kVARh (MVARh or GVARh) reactive power demand) $\leq 2$ % for $I > 0.1 I_{\text{nom}}$ , $V > 0.1 V_{\text{nom}}$ and $\left|\cos\varphi\right|$ (p.f.) $\geq 0.707$ ber of trips Up to 9 digits automatic reclosing Up to 9 digits (segregated according 2<sup>nd</sup> cycle) ed interrupted current Up to 4 digits acc. to pole) hours counter Up to 7 digits ge Overshoot of an adjustable current threshold (element 50-1, BkrClosed I<sub>MIN</sub>) aker monitoring methods On r.m.s.-value basis: $\Sigma I, \Sigma I^{x}, 2 P$ On instantaneous value basis: $\Sigma i^2 t$ value acquisition/ Phase-selective One limit value each per subfunction per of statistical values Up to 13 digits monitoring r two binary inputs ning aids on test. measured values, ker test by means unction, a test fault report, messages ronization Binary input, communication oup switchover of the function parameters available setting groups 4 (parameter group A, B, C and D) Via keypad, DIGSI using the operator performed interface, protocol using port B or binary input

\*) With rated frequency.

#### Breaker control

Number of switching units Depends on the binary inputs and outputs available Interlocking Freely programmable Messages Feedback messages, closed, open, intermediate position Control commands Single command / double command Switching command to circuit-1-, 11/2- and 2-pole breaker Programmable logic controller PLC logic, graphic input tool Local control Control via menu, assignment of function keys Remote control Via communication interfaces, using a substation automation and control system (e.g. SICAM), using DIGSI 4 (e.g. via modem)

#### **CE conformity**

This product is in conformity with the Directives of the European Communities on the harmonization of the laws of the Member States relating to electromagnetic compatibility (EMC Council Directive 89/336/EEC) and electrical equipment designed for use within certain voltage limits (Council Directive 73/23/EEC).

This unit conforms to the international standard IEC 60255, and the German standard DIN 57435/Part 303 (corresponding to VDE 0435/Part 303).

Further applicable standards: ANSI/IEEE C37.90.0 and C37.90.1.

The unit conforms to the international standard IEC 60255, and the German standard DIN 57435/Part 303 (corresponding to VDE 0435/Part 303).

This conformity is the result of a test that was performed by Siemens AG in accordance with Article 10 of the Council Directive complying with the generic standards EN 50081-2 and EN 50082-2 for the EMC Directive and standard EN 60255-6 for the "low-voltage Directive".

#### Notes

Subject to change without prior notice.

We reserve the right to include modifications.

Drawings are not binding.

If not stated otherwise, all dimensions in this catalog are given in mm/inch.

The information in this document contains general descriptions of the technical options available, which do not always have to be present in individual cases. The required features should therefore be specified in each individual case at the time of closing the contract.

#### Selection and ordering data

Description	Order No.				
7SJ80 overcurrent protection device	7SJ80	- 0 0 0		- 🗆 🗆	
<i>Housing, binary inputs and outputs</i> Housing 1/6 19", 4 x <i>I</i> , 3 BI, 5 BO (2 changeover/Form C), 1 live status contact					
Housing 1/6 19", 4 x <i>I</i> , 7 BI, 8 BO (2 changeover/Form C), 1 live status contact	2		see ne	 ext page	 ;
Housing 1/6 19", 4 x <i>I</i> , 3 x <i>V</i> , 3 BI, 5 BO (2 changeover/Form C), 1 live status contact	3				
Housing 1/6 19", 4 x <i>I</i> , 3 x <i>V</i> , 7 BI, 8 BO (2 changeover/Form C), 1 live status contact	4				
Measuring inputs, default settings					
$I_{ph} = 1 \text{ A / 5 A}, I_e = 1 \text{ A / 5 A}$ $I_{ph} = 1 \text{ A / 5 A}, I_{ee} \text{ (sensitive)} = 0.001 \text{ to } 1.6 \text{ A / } 0.005 \text{ to } 8 \text{ A}$	1				
Rated auxiliary voltage           24 V / 48 V DC           60 V / 110 V / 125 V / 220 V DC, 115 V, 230 V AC		1 5			
Unit version		D			
Surface-mounting housing, screw-type terminal Flush-mounting housing, screw-type terminal		B E			
Region-specific default and language settings Region DE, IEC, language German (language selectable), standard fro	nt	A			
Region World, IEC/ANSI, language English (language selectable), star	ndard front	В			
Region US, ANSI, language US-English (language selectable), US from		С	-		
Region FR, IEC/ANSI, language French (language selectable), standar		D			
Region World, IEC/ANSI, language Spanish (language selectable), stand		Ε			
Region World, IEC/ANSI, language Italian (language selectable), standa		F	ł		
Region RUS, IEC/ANSI, language Russian (language selectable), standar		G	ł		
Region CHN, IEC/ANSI, language Chinese (language not changeable),	Chinese front	K	]		

Selection and ordering data	Description	Order No.			Orc cod	
	7SJ80 overcurrent protection device	<i>7SJ80</i> □□	-00000	-0000		2 🗆
	<i>Port B (at bottom of device, rear)</i> No port		0			
	IEC 60870-5-103 or DIGSI 4/modem, electrical RS232		1	see		
	IEC 60870-5-103 or DIGSI 4/modem, electrical RS485		2	followin	g	
	IEC 60870-5-103 or DIGSI 4/modem, optical 820 nm, ST con	nector	3	page		
	PROFIBUS-DP Slave, electrical RS485		9		L 0	Α
	PROFIBUS-DP Slave, optical, double ring, ST connector		9		L 0	B
	MODBUS, electrical RS485		9		L 0	D
	MODBUS, optical 820 nm, ST connector		9		L 0	E
	DNP 3.0, electrical RS485		9		L 0	G
	DNP 3.0, optical 820 nm, ST connector		9		L 0	Η
	IEC 60870-5-103, redundant, electrical RS485, RJ45 connecto	r	9		L 0	Ρ
	IEC 61850, 100 Mbit Ethernet, electrical, double, RJ45 connec	tor	9		L 0	R
	IEC 61850, 100 Mbit Ethernet, optical, double, LC connector		9		L 0	S
	Port A (at bottom of device, in front) No port		0			
	With Ethernet interface (DIGSI, not IEC 61850), RJ45 connector	r	6			
	Measuring/fault recording					
	With fault recording With fault recording, average values, min/max values			1		

#### Selection and ordering data

· · · ·	otection device	75J80🗆 – 🗆 🗆 🗆 –	
Designation	ANSI No.	Description	
Basic version	50/51 50N/51N 50N(s)/51N(s) <sup>1</sup> 87N <sup>2)</sup> 49 74TC 50BF 46 37 86	Time-overcurrent protection phase <i>I</i> >, <i>I</i> >>, <i>I</i> >>>, <i>I</i> <sub>P</sub> >>, <i>I</i> <sub>P</sub> >>>, <i>I</i> <sub>P</sub> >>>, <i>I</i> <sub>P</sub> >>>, <i>I</i> <sub>E</sub> >>, <i>I</i>	F
Desisonation dimension			- /
Basic version + directio	0	voltage and frequency protection	
	67N	Directional overcurrent protection ground $I_{\rm E}$ , $I_{\rm E}$ , $I_{\rm Ep}$	
	67N(s) <sup>1)</sup> 64/59N	Directional sensitive ground fault protection <i>I</i> <sub>EE</sub> >, <i>I</i> <sub>EE</sub> >>, <i>I</i> <sub>EEp</sub> Displacement voltage	
	27/59 81U/O	Under-/overvoltage	
	47	Under-/overfrequency, <i>f</i> <, <i>f</i> > Phase rotation	
	32/55/81R	Flexible protection functions (current and voltage parameters): Protective function for voltage, power, power factor, frequency change	F
Basic version + direction	onal phase & ground overc	urrent, directional sensitive ground fault,	
voltage and frequency	protection		
	67	Directional overcurrent protection phase $L > L > L$	
	67 67N	<i>I</i> >, <i>I</i> >>, <i>I</i> <sub>p</sub> Directional overcurrent protection phase	
•		I>, I>>, I <sub>p</sub>	
•	67N 67N(s) <sup>1)</sup>	$I >, I >>, I_p$ Directional overcurrent protection ground $I_E >, I_E >>, I_{Ep}$ Directional sensitive ground fault protection $I_{EE} >, I_{EE} >>, I_{EEp}$	
•	67N	$I >, I >>, I_p$ Directional overcurrent protection ground $I_E >, I_E >>, I_{Ep}$ Directional sensitive ground fault protection $I_{EE} >, I_{EE} >>, I_{Ep}$ Displacement voltage	
•	67N 67N(s) <sup>1)</sup> 64/59N 27/59 81U/O	$I>, I>>, I_p$ Directional overcurrent protection ground $I_E>, I_E>>, I_{Ep}$ Directional sensitive ground fault protection $I_{EE}>, I_{EE}>>, I_{Ep}$ Displacement voltage Under-/overvoltage Under-/overfrequency, $f<, f>$	
•	67N 67N(s) <sup>1)</sup> 64/59N 27/59 81U/O 47	$I>, I>>, I_p$ Directional overcurrent protection ground $I_E>, I_E>>, I_{Ep}$ Directional sensitive ground fault protection $I_{EE}>, I_{EE}>>, I_{Ep}$ Displacement voltage Under-/overvoltage Under-/overfrequency, $f<, f>$ Phase rotation	
•	67N 67N(s) <sup>1)</sup> 64/59N 27/59 81U/O	$I>, I>>, I_p$ Directional overcurrent protection ground $I_E>, I_E>>, I_{Ep}$ Directional sensitive ground fault protection $I_{EE}>, I_{EE}>>, I_{Ep}$ Displacement voltage Under-/overvoltage Under-/overfrequency, $f<, f>$ Phase rotation Flexible protection functions (current and voltage	
	67N 67N(s) <sup>1)</sup> 64/59N 27/59 81U/O 47	$I>, I>>, I_p$ Directional overcurrent protection ground $I_E>, I_E>>, I_{Ep}$ Directional sensitive ground fault protection $I_{EE}>, I_{EE}>>, I_{Ep}$ Displacement voltage Under-/overvoltage Under-/overfrequency, $f<, f>$ Phase rotation	F
	67N 67N(s) <sup>1)</sup> 64/59N 27/59 81U/O 47 32/55/81R	$I>, I>>, I_p$ Directional overcurrent protection ground $I_E>, I_E>>, I_{Ep}$ Directional sensitive ground fault protection $I_{EE}>, I_{EE}>>, I_{Ep}$ Displacement voltage Under-/overvoltage Under-/overfrequency, $f<, f>$ Phase rotation Flexible protection functions (current and voltage parameters): Protective function for voltage, power,	F
	67N 67N(s) <sup>1)</sup> 64/59N 27/59 81U/O 47 32/55/81R	$I>, I>>, I_p$ Directional overcurrent protection ground $I_E>, I_E>>, I_{Ep}$ Directional sensitive ground fault protection $I_{EE}>, I_{EE}>>, I_{Ep}$ Displacement voltage Under-/overvoltage Under-/overfrequency, $f<, f>$ Phase rotation Flexible protection functions (current and voltage parameters): Protective function for voltage, power, power factor, frequency change	F(
Basic version + directio	67N 67N(s) <sup>1)</sup> 64/59N 27/59 81U/O 47 32/55/81R	$I>, I>>, I_p$ Directional overcurrent protection ground $I_E>, I_E>>, I_{Ep}$ Directional sensitive ground fault protection $I_{EE}>, I_{EE}>>, I_{Ep}$ Displacement voltage Under-/overvoltage Under-/overfrequency, $f<, f>$ Phase rotation Flexible protection functions (current and voltage parameters): Protective function for voltage, power, power factor, frequency change	F(
Basic version + directio	67N 67N(s) <sup>1)</sup> 64/59N 27/59 81U/O 47 32/55/81R onal phase overcurrent, vol 67 27/59 81U/O	$I>, I>>, I_{p}$ Directional overcurrent protection ground $I_{E}>, I_{E}>>, I_{Ep}$ Directional sensitive ground fault protection $I_{EE}>, I_{EE}>>, I_{Ep}$ Displacement voltage Under-/overvoltage Under-/overfrequency, <i>f</i> <, <i>f</i> > Phase rotation Flexible protection functions (current and voltage parameters): Protective function for voltage, power, power factor, frequency change Itage and frequency protection + synch-check Directional overcurrent protection phase $I>, I>>, I_{p}$ Under-/overvoltage Under-/overvoltage Under-/overvoltage Under-/overvoltage Under-/overvoltage Under-/overvoltage	F
Basic version + directio	67N 67N(s) <sup>1)</sup> 64/59N 27/59 81U/O 47 32/55/81R onal phase overcurrent, vol 67 27/59 81U/O 47	$I>, I>>, I_{p}$ Directional overcurrent protection ground $I_{E}>, I_{E}>>, I_{Ep}$ Directional sensitive ground fault protection $I_{EE}>, I_{EE}>>, I_{EEp}$ Displacement voltage Under-/overfrequency, $f<, f>$ Phase rotation Flexible protection functions (current and voltage parameters): Protective function for voltage, power, power factor, frequency change Itage and frequency protection + synch-check Directional overcurrent protection phase $I>, I>>, I_{p}$ Under-/overvoltage Under-/overfrequency, $f<, f>$ Phase rotation	F(
Basic version + directio	67N 67N(s) <sup>1)</sup> 64/59N 27/59 81U/O 47 32/55/81R onal phase overcurrent, vol 67 27/59 81U/O	$I>, I>>, I_{p}$ Directional overcurrent protection ground $I_{E}>, I_{E}>>, I_{Ep}$ Directional sensitive ground fault protection $I_{EE}>, I_{EE}>>, I_{Ep}$ Displacement voltage Under-/overvoltage Under-/overfrequency, <i>f</i> <, <i>f</i> > Phase rotation Flexible protection functions (current and voltage parameters): Protective function for voltage, power, power factor, frequency change Itage and frequency protection + synch-check Directional overcurrent protection phase $I>, I>>, I_{p}$ Under-/overvoltage Under-/overvoltage Under-/overvoltage Under-/overvoltage Under-/overvoltage Under-/overvoltage	F
Basic version + directio	67N 67N(s) <sup>1)</sup> 64/59N 27/59 81U/O 47 32/55/81R 0nal phase overcurrent, vol 67 27/59 81U/O 47 25 81R	$I>, I>>, I_p$ Directional overcurrent protection ground $I_E>, I_E>, I_{Ep}$ Directional sensitive ground fault protection $I_{EE>}, I_{EE>}, I_{EEp}$ Displacement voltage Under-/overvoltage Under-/overfrequency, $f<, f>$ Phase rotation Flexible protection functions (current and voltage parameters): Protective function for voltage, power, power factor, frequency change Itage and frequency protection + synch-check Directional overcurrent protection phase $I>, I>>, I_p$ Under-/overvoltage Under-/overfrequency, $f<, f>$ Phase rotation Synch-check Flexible protection functions (current and voltage parameters): Protective function for voltage,	
Basic version + directio	67N 67N(s) <sup>1)</sup> 64/59N 27/59 81U/O 47 32/55/81R 0nal phase overcurrent, vol 67 27/59 81U/O 47 25 81R 0cator	$I>, I>>, I_p$ Directional overcurrent protection ground $I_E>, I_E>, I_{Ep}$ Directional sensitive ground fault protection $I_{EE>}, I_{EE>}, I_{EEp}$ Displacement voltage Under-/overvoltage Under-/overfrequency, $f<, f>$ Phase rotation Flexible protection functions (current and voltage parameters): Protective function for voltage, power, power factor, frequency change Itage and frequency protection + synch-check Directional overcurrent protection phase $I>, I>>, I_p$ Under-/overvoltage Under-/overfrequency, $f<, f>$ Phase rotation Synch-check Flexible protection functions (current and voltage parameters): Protective function for voltage, frequency change	
Basic version + directio	67N 67N(s) <sup>1)</sup> 64/59N 27/59 81U/O 47 32/55/81R 0nal phase overcurrent, vol 67 27/59 81U/O 47 25 81R	$I >, I >>, I_p$ Directional overcurrent protection ground $I_E >, I_E >>, I_{Ep}$ Directional sensitive ground fault protection $I_{EE} >, I_{EE} >>, I_{Ep}$ Displacement voltage Under-/overvoltage Under-/overfrequency, $f <, f >$ Phase rotation Flexible protection functions (current and voltage parameters): Protective function for voltage, power, power factor, frequency change Itage and frequency protection + synch-check Directional overcurrent protection phase $I >, I >>, I_p$ Under-/overvoltage Under-/overfrequency, $f <, f >$ Phase rotation Synch-check Flexible protection functions (current and voltage parameters): Protective function for voltage, frequency change	

#### Basic version included

 Depending on the ground current input the function will be either sensitive (*I<sub>ee</sub>*) or non-sensitive (*I<sub>e</sub>*).

2) 87N (REF) only with sensitive ground current input (position 7 = 2).

3) Only if position 6 = 1 or 2.

4) Only if position 6 = 3 or 4.

5) Only if position 6 = 3 or 4 and position 16 = 0 or 1.

#### Sample order

Positio	n	Order No. + Order code
		7SJ8041-5EC96-3FC1+L0G
6	I/O's: 7 BI/8 BO, 1 live status contact	4
7	Current transformer: $I_{\text{ph}} = 1 \text{ A} / 5 \text{ A}$ , $I_{\text{e}} = 1 \text{ A} / 5 \text{ A}$	1
8	Power supply: 60 to 250 V DC, 115 V AC to 230 V AC	5
9	Unit version: Flush-mounting housing, screw-type terminals	E
10	Region: US, English language (US); 60 Hz, ANSI	С
11	Communication: System interface: DNP 3.0, RS485	9 L0G
12	Communication: Ethernet interface (DIGSI, not IEC 61850)	6
13	Measuring/fault recording: Extended measuring and fault record	rds 3
14/15	Protection function package: Basic version plus directional TO	C FC
16	With auto-reclosure	1

#### Accessories

Description	Order No.
DIGSI 4	
Software for configuration and operation of Siemens protection units	
running under MS Windows 2000/XP Professional Edition/Vista.	
Basis Full version with license for 10 computers, on CD-ROM	
(authorization by serial number)	7XS5400-0AA00
Professional DIGSI 4 Basis and additionally SIGRA (fault record analysis),	
CFC Editor (logic editor), Display Editor (editor for default	
and control displays) and DIGSI 4 Remote (remote operation)	7XS5402-0AA00
Professional + IEC 61850	
Complete version:	
DIGSI 4 Basis and additionally SIGRA (fault record analysis),	
CFC Editor (logic editor), Display Editor (editor for default	
and control displays) and DIGSI 4 Remote (remote operation)	
+ IEC 61850 system configurator	7XS5403-0AA00
Terminals	
Voltage terminal block C or block E	C53207-A406-D181-1
Voltage terminal block D (inverse print)	C53207-A406-D182-
Current terminal block 4 x I	C53207-A406-D185-
Current terminal block 3 x $I$ , 1 x $I_{Ns}$ (sensitive)	C53207-A406-D186-
Current terminal short-circuit links (3 pieces)	C53207-A406-D193-
Voltage terminal short-circuit links (6 pieces)	C53207-A406-D194-
Varistor/Voltage arrester	
Voltage arrester for high-impedance REF protection	
125 Vrms; 600 A; 1S/S 256	C53207-A401-D76-1
240 Vrms; 600 A; 1S/S 1088	C53207-A401-D77-1
Manual for 7SJ80	
English	E50417-G1140-C343-A4
German	E50417-G1100-C343-A4
- Mounting rail set for 19" rack	C73165-A63-D200-1




Fig. 5/74 7SJ801 connection diagram




Fig. 5/75 7SJ802 connection diagram




Fig. 5/76 7SJ803 connection diagram






Fig. 5/77 7SJ804 connection diagram



Rear view









Fig. 17/22 75J80/75K80 protection relays for panel flush mounting/cubicle mounting





SAAR23